



ECLIPSE

USER MANUAL

WARNING!



**ADHERE STRICTLY TO THESE AND ALL OTHER
SAFETY INSTRUCTIONS AND GUIDELINES!**

- Please read and understand all instruction manuals before use.
- The Eclipse GEO3.5 is not a toy. PAINTBALL SAFETY RULES MUST BE FOLLOWED AT ALL TIMES.
- Careless or improper use, including failure to follow instructions and warnings within this User Manual and attached to the GEO3.5 could cause death or serious injury.
- Do not remove or deface any warnings attached to the GEO3.5.
- Paintball industry standard eye/face/ear and head protection designed specifically to stop paintballs and meeting ASTM standard F1776 (USA) or CE standard (Europe) must be worn by the user and any person within range. Proper protection must be worn during assembly, cleaning and maintenance.
- Hearing protection should be worn.
- Never shoot at a person who is not wearing proper protection.
- Never look directly into the barrel of the marker. Accidental discharge into the eyes may cause permanent injury or death. Never look into the barrel or breech area of the GEO3.5 whilst the marker is switched on and able to fire.
- Keep the GEO3.5 switched off until ready to shoot.
- Treat every marker as if it is loaded and ready to fire.
- The electronic on/off is the markers safety, always switch off the marker when not in use.
- Always fit a barrel-blocking device to the GEO3.5 when not in use.
- Always remove all paintballs from the GEO3.5 when not in use on the field of play.
- Never point the GEO3.5 at anything you do not intend to shoot.
- Do not shoot at persons within close range.
- Do not field strip or remove any parts while the marker is pressurised.
- Do not pressurise the GEO3.5 without all the components of the marker correctly installed, as high-pressure gas may be emitted.
- Do not fire the GEO3.5 without the bolt correctly installed.
- Never put your finger or any foreign objects into the paintball feed tube of the GEO3.5.
- Never allow pressurised gas to come into contact with any part of your body
- Always remove the first stage regulator and relieve all residual gas pressure from the GEO3.5 before disassembly.
- Always remove the first stage regulator and relieve all residual gas pressure from the GEO3.5 for transport and storage.
- Always follow guidelines given with your first stage regulator for safe transportation and storage.
- Always store the GEO3.5 in a secure place.
- Persons under 18 years of age must have adult supervision when using or handling the GEO3.5.
- Observe all local and national laws, regulations and guidelines.

WARNING!



ADHERE STRICTLY TO THESE AND ALL OTHER SAFETY INSTRUCTIONS AND GUIDELINES!

- Use only professional paintball fields where codes of safety are strictly enforced.
- Use compressed air/nitrogen only. Do not use any other compressed gas or pressurised liquid including CO2.
- Always follow instructions, warnings and guidelines given with any first stage regulator you use with the GEO3.5.
- Use 0.68 inch calibre paintballs only.
- Always measure your marker's velocity before playing paintball, using a suitable chronograph.
- Never shoot at velocities in excess of 300 feet (91.44 meters) per second, or at velocities greater than local or national laws allow.
- Any installations, modifications or repairs should be carried out by a qualified individual at a licensed and insured paintball facility.

THIS USER MANUAL MUST ACCOMPANY THE PRODUCT IN THE EVENT OF RESALE OR NEW OWNERSHIP. SHOULD YOU BE UNSURE AT ANY STAGE YOU MUST SEEK EXPERT ADVICE (SEE SERVICE CENTRES PAGE 66).



This Users Manual is in English.

It contains important safety guidelines and instructions. Should you be unsure at any stage, or unable to understand the contents of this manual you must seek expert advice.



Le mode d'emploi est en Anglais.

Il contient des instructions et mesures de sécurité importantes. En cas de doute, ou s'il vous est impossible de comprendre le contenu du mode d'emploi, demandez conseil à un expert.



Este manual de usuarios (operarios)

Usuarios está en Inglés. Contiene importantes normas de seguridad e instrucciones. Si no está seguro de algún punto o no entiende los contenidos de este manual debe consultar con un experto.



Diese Bedienungs - und Benutzeranleitung ist in Englisch.

Sie enthält wichtige Sicherheitsrichtlinien und -bestimmungen. Sollten Sie sich in irgendeiner Weise unsicher sein, oder den Inhalte dies Heftes nicht verstehen, lassen Sie sich bitte von einen Experten beraten.

CONTENTS

USING THE GEO3.5 (06-26)

Details on setting up the GEO3.5 and information on the user interface. This section is essential reading for everyone.

06	Factory set-up guide
07	Installing a 9V Battery
08	Switching on the GEO3.5 Switching off the GEO3.5 Firing the GEO3.5
09	Using the break beam sensor system
10	The GEO3.5 navigation console
11	Installing a barrel
12	Trigger adjustment
14	Attaching a loader
15	The gas through pipe
16	Installing a pre-set air system
18	Velocity adjustment
19	Solenoid Flow Restrictor (SFR)
20	Unloading the GEO3.5
21	Storage and transportation
22	The user interface The run screen layout
23	The BBSS indicator The AUX out indicator
24	The sound indicator The trigger detection indicator
25	The lock indicator The battery level indicator The game timer The shot counter
26	The actual rate of fire The peak rate of fire The menu system

ADVANCED SET-UP (27-41)

In depth information on setting up the GEO3.5.

27	Accessing the menu system Moving around the menus Altering parameters
28	The menu system
29	<i>PRESET</i> - The preset menu <i>LOAD</i> - The load pre-set parameter <i>SAVE</i> - The save pre-set parameter
30	<i>FIRE MODE</i> - The fire mode parameter <i>ROF CAP</i> - The rate of fire cap parameter <i>BS ON ROF</i> - The maximum rate of fire parameter <i>BS OFF ROF</i> - Rate of fire with BBSS off parameter
31	<i>RAMP SETUP</i> - The ramp set-up menu <i>TYPE</i> - The ramp type parameter <i>RATE</i> - The linear ramp rate parameter
32	<i>SEMI SHOTS</i> - The ramp start parameter <i>KICK IN</i> - The ramp kick-in parameter <i>SUSTAIN</i> - The sustain rate parameter <i>RESTART</i> - The ramp restart parameter
33	<i>TIMING</i> - The timing menu <i>DWELL</i> - The dwell parameter <i>FSD COMP</i> - The first shot drop-off compensation parameter <i>FSD DLY</i> - The first shot drop-off delay parameter
34	<i>FILTER</i> - The filter menu <i>DE-BOUNCE</i> - The de-bounce parameter <i>EMPTY</i> - The breech empty time parameter <i>FULL</i> - The breech full time parameter
35	<i>PULL TM</i> - The trigger pull time parameter <i>PULL PT</i> - The trigger pull point parameter <i>RELEASE PT</i> - The trigger release point parameter
36	Basic trigger filter set-up Advanced trigger filter set-up <i>HARDWARE</i> - The hardware menu

37	<i>TRIGGER</i> - The trigger parameter <i>SOLENOID</i> - The solenoid power parameter <i>SOUND</i> - The sound parameter <i>TONES</i> - The tones parameter
38	<i>BACKLIGHT</i> - The backlight parameter <i>RED LEVEL</i> - The backlight red level parameter <i>GRN LEVEL</i> - The backlight green level parameter <i>BLU LEVEL</i> - The backlight blue level parameter
39	<i>CONTRAST</i> - The LCD contrast level parameter <i>AUX OUT</i> - The AUX out parameter <i>DBL CLICK</i> - The double clicking parameter <i>AUTO OFF</i> - The auto off parameter
40	<i>TRAINING</i> - The training parameter <i>SHOT COUNT</i> - The shot count menu <i>GAUGE</i> - The gauge parameter <i>GAUGE MAX</i> - The gauge max parameter
41	<i>GAME TIMER</i> - The game timer menu <i>GAME</i> - The game timer parameter <i>ALARM</i> - The alarm parameter <i>START</i> - The start parameter

MAINTENANCE (42-59)

A guide to cleaning and performing routine maintenance on specific areas of the GEO3.5.

42	The break beam sensor system
44	The SL4 inline regulator assembly
46	Advanced inline regulator maintenance
47	Cleaning the body filter
48	Maintaining the bolt system
50	Advanced bolt system maintenance
51	Removing the frame
52	Attaching the frame
53	Maintaining the SFR
54	The trigger assembly
56	The GEO3.5 solenoid assembly
59	The Push On Purge System (POPS)

FAULT FINDING (61-65)

Information on how to resolve any problems that might arise with your GEO3.5.

SERVICE CENTRES (66)

Information on the location of your nearest Eclipse Service Centre.

TECHNICAL RESOURCES (67-78)

Illustrated diagrams and component lists for key areas of the GEO3.5.

67	Operational overview
68	GEO3.5 parts list
70	Eclipse shaft barrel system
71	SL4 inline regulator assembly
72	GEO3.5 bolt system
73	GEO3.5 solenoid assembly
74	GEO3.5 Push On Purge System (POPS) assembly
75	Trigger assembly Clamping feed tube assembly
76	GEO3.5 circuit board
77	Common screw size chart
78	Common o-ring size chart

MENU TREE (79-82)

A quick reference guide to the user interface.

ECLIPSE E-PORTAL (83)

Information on the Eclipse E-Portal upgrade for GEO3.5.

INDEX (84-85)

GEO3.5 manual index

WARRANTY CARD (INSERT)

Tear-out product registration card to be completed and returned. Alternatively register online at www.planeteclipse.com.

FACTORY SET-UP GUIDE

Before using the GEO3.5 it is important to make sure the SL4 inline regulator, solenoid flow restrictor (SFR) and all electronically controlled parameters are set correctly. ANY of these can have a negative effect on the performance of the marker if set incorrectly.

The steps below will restore the GEO3.5 settings to the factory settings. These settings will give the GEO3.5 a more balanced performance, ideal for most users.

Inline Regulator Output Pressure

Check the inline regulator adjuster screw is set to 4 1/2 turns clockwise from its maximum out position (*see figure 1A*). This will ensure the SL4 inline regulator is set to an output pressure that will not damage the GEO3.5 when supplied with compressed air/nitrogen (see page 18 for more information on SL4 inline regulator adjustment).

Solenoid Flow Restrictor Settings

Check that the solenoid flow restrictor (*see figure 1B*) is set as pictured. See page 19 for more information on the solenoid flow restrictor.

Electronically Controlled Parameters

Load the FACTORY PRESET (*see figure 1C*) stored on the GEO3.5 circuit board. This pre-set will restore all the electronic parameters to their default settings. See page 29 on loading the FACTORY PRESET.




FIG 1A



FIG 1B



FIG 1C

WARNING!



De-gas your marker, discharging any stored gas in a safe direction, and remove the barrel, loader, air system and any paintballs to make the marker easier and safer to work on.

INSTALLING A 9V BATTERY

Ensure that the GEO3.5 is switched off. Lay the marker on a flat surface in front of you with the feed tube furthest away and with the barrel pointing to the right.

Use a 5/64" (2mm) hex key to remove the two countersunk screws that hold the rubber grip onto the frame (see figure 2A). Peel the grip to the right to expose the circuit board within the frame.

Remove the fitted battery by sliding your thumb or finger into the recess below the battery and levering the battery out of the frame (see figure 2B).

DO NOT pull on the top of the battery to remove it as this can cause the battery terminals to bend and will result in a poor electrical connection.

Fit a 9-volt alkaline battery (type PP3, 6LR61 or MN1604) into the recess with the battery terminals away from you. The positive terminal should be on the right hand side, nearest to the front side of the frame (see figure 2C).

Planet Eclipse recommends using a branded high quality alkaline 9V battery. Budget and rechargeable batteries may cause performance issues.

Ensure that all of the wires are within the recess of the frame and away from the trigger, micro-switch and OPTO sensors so as not to interfere with their operation. Replace the rubber grip and screw in the two countersunk screws.

DO NOT OVER-TIGHTEN THE GRIP SCREWS



FIG 2A



FIG 2B



FIG 2C

SWITCHING ON THE GEO3.5

To switch on the GEO3.5 press the  button twice in quick succession, referred to elsewhere in this manual as 'double-clicking'. The GEO3.5 can also be switched on by pushing and holding the  button (see figure 3A).¹

SWITCHING OFF THE GEO3.5

Press and hold the  button (see figure 3A) until the display shows "TURN OFF". Release the  button and re-press it to turn off the GEO3.5. Alternatively double click the  button to enter the menu tree then press  to turn off the GEO3.5.¹

FIRING THE GEO3.5

Pull the trigger (labelled **A** in figure 3B) to fire the GEO3.5. The entire firing sequence is controlled electronically by the GEO3.5 circuit board, enabling any user to easily achieve high rates of fire.

WARNING!



Planet Eclipse advises not to dry fire/shoot the marker without paintballs. Prolonged dry firing MAY lead to damage/wear of the internal components of the marker.

¹ The double clicking feature is user selectable, factory default is set to on. It can be turned off using the double click parameter in the hardware menu (see page 39).

FIG 3A



FIG 3B



USING THE BREAK BEAM SENSOR SYSTEM

The Break Beam Sensor System, referred to elsewhere in this manual as 'BBSS' is used to detect when a paintball is ready to be fired from the GEO3.5. If no paintball is ready then the BBSS will inhibit the GEO3.5 from firing. This prevents the GEO3.5 from "chopping" paintballs that are not fully loaded into the marker.¹

To switch off the BBSS, press and hold the  button for 0.5 seconds (see [figure 4A](#)). The BBSS indicator on the top right of the LCD will change from  (enabled) to  (disabled).

To switch the BBSS back on, press and hold the  button for 0.5 seconds. The indicator will change back to .

When the BBSS is enabled, the indicator will change depending upon whether the system has detected a ball or not. When no ball has been detected the indicator will look like this . When a ball has been detected the icon changes to look like this .

Additional features of the GEO3.5's Break Beam Sensor System are covered in full on page 23 of this operators manual.

WARNING!



The Geo3.5 may still fire even if there is no paintball in the breach. Always ensure all safety guidelines are followed when the Geo3.5 is switched on.

¹ When the GEO3.5 is turned on, the BBSS is automatically enabled.



FIG 4A

THE GEO3.5 NAVIGATION CONSOLE

At the rear of the GEO3.5 grip frame you will find the navigation console (see figure 5A) which is used for:

- Turning the GEO3.5 on and off using the  button.
- Scrolling through menus with the  and  buttons.
- Selecting parameters to edit using the  button.
- Editing parameters using the  and  buttons.
- Turning the GEO3.5 BBSS on and off using the  button (push and hold).
- Resetting recorded values using the  button (push and hold).
- Controlling the game timer with the  button (quick push and release).
- Scrolling through the various run screens using the  button (quick push and release).

WARNING!



The backlight on the LCD display turns off after a period of time. When this happens the marker is still on and able to fire. To adjust the LCD backlight see page 38.

 PREVIOUS / RAISE

 SELECT

 NEXT / LOWER



FIG 5A

INSTALLING A BARREL

Every GEO3.5 comes complete with an Eclipse Shaft4 barrel (see page 70). The bore size of the Shaft4 barrel back is engraved on the barrel back just in front of the bore threads.

To install the Shaft4 barrel, firstly screw the barrel tip and barrel back sections together. The threads on the Shaft4 barrel tip are reverse threaded. To screw the two sections together, with the barrel pointing away from you, turn the barrel tip in a clockwise direction (see figure 6A).

While pointing the GEO3.5 marker in a safe direction, insert the assembled Shaft4 barrel into the front of the GEO3.5 body and screw the Shaft4 barrel into the GEO3.5 (in a counter-clockwise direction). Continue to screw the Shaft4 barrel into the GEO3.5 body until the barrel becomes snug in the body (see figure 6B). DO NOT over tighten the barrel.

Install a barrel blocking device over the barrel such as the Eclipse barrel sock¹ supplied with the GEO3.5 (see figure 6C).²

You have now installed the barrel.

WARNING!



Make sure the marker is turned off and that no paintballs are in the marker or loader before installing a barrel.

Always fit a barrel-blocking device to the GEO3.5 when not in use.

¹ The Eclipse barrel sock that comes with the GEO3.5 may differ from that pictured in this manual.
² Instruction on using the Eclipse barrel sock can be found on the Eclipse barrel sock warning label.



FIG 6A



FIG 6B



FIG 6C

TRIGGER ADJUSTMENT

The GEO3.5 provides the user with the option to use either a micro-switch or an OPTO sensor (default OPTO) as the means for detecting trigger pulls. Before you begin to adjust and set your trigger, you must first select the method of trigger detection that you wish to use by entering the main menu and making your selection from the hardware menu (see page 37).

There are five adjustment points on the trigger – the front stop screw, the rear stop screw, the magnet return strength screw, the micro-switch activation screw and the spring return strength screw.

FIGURE 7A KEY

- A** - Trigger leaf spring
- B** - Spring return strength screw
- C** - Trigger pin retaining screw
- D** - Front stop screw
- E** - Magnet return strength screw
- F** - Micro-switch activation screw
- G** - Rear stop screw
- H** - OPTO sensor activation prong

The front stop screw is used to set the amount of trigger travel prior to the marker firing. Turn this screw clockwise to reduce the amount of travel. Do not turn the screw too far or the trigger will be pushed past the firing point and the marker will not fire. Turn this screw counter-clockwise to increase the amount of trigger travel (see figure 7B).

The rear stop screw is used to set the amount of travel after the marker has fired. Turn this screw clockwise to reduce the amount of travel. Do not turn the screw too far or the trigger will be prevented from reaching its firing point and the marker will not work. Turn this screw counter-clockwise to increase the amount of travel (see figure 7C).




FIG 7A




FIG 7B




FIG 7C

CONTINUED


The magnet return strength screw is used to adjust the amount of force with which the trigger is returned to its rest position by the magnet. Turn the screw clockwise to increase the amount of force. Do not turn the screw too far or it will negate the position of the front stop screw. Turn the screw counter-clockwise to reduce the amount of force. Do not turn the screw too far or there may not be enough force to return the trigger (*see figure 7D*).

The micro-switch activation screw is used to adjust the point in the trigger pull at which the micro-switch is activated (only if the Trigger parameter on page 37 is set to 'SWITCH'). Turn the screw clockwise to decrease the amount of trigger travel to the activation point. Turn the screw counter-clockwise to increase the amount of trigger travel to the activation point (*see figure 7E*). Do not set the micro-switch activation screw too far out when using the OPTO sensors, as the screw can stop against the micro-switch before the trigger prong enters the OPTO sensors.

The spring return strength screw is used to adjust the spring strength that returns the trigger to its resting position. Turn the screw clockwise to increase the amount of spring return strength in the trigger pull. Turn this screw counter-clockwise to reduce the amount of spring return strength in the trigger pull. Do not turn the screw too far counter-clockwise or there will not be enough force to return the trigger consistently (*see figure 7F*).

When setting the trigger it is important to ensure that the electronic trigger detection is working correctly. When the trigger is fully depressed the Trigger Detection Indicator (TDI) should point upwards   . When the trigger is fully released the TDI should point downwards   .

For more information, see understanding the Trigger Detection Indicator (TDI) on page 24 and the Filter menu on pages 34-36.



WARNING!



The trigger has been factory set to provide the necessary return force and travel to minimize the risk of accidental discharge.

DO NOT make any adjustment to the trigger return strength, trigger actuation point, trigger actuation pre-travel or trigger post actuation travel that could result in an increased risk of accidental discharge.

This includes, but is not limited to, reducing the magnetic return force, reducing the spring return force, reducing the trigger pre-travel to actuation point or reducing the trigger post-travel after the actuation point.

The magnet return strength screw (see Fig7A - E) must NOT be adjusted so that any part of the screw is visible beyond the inner surface of the trigger (see Fig7D). The magnet return strength screw must NEVER be removed from the trigger. Incorrect adjustment of the magnet return strength screw could result in serious injury or death.

Prior to each use and before switching on the marker, visually inspect the trigger to verify that all adjustment screws are in place and that no adjustments have been made that may result in accidental discharge. If in doubt, seek professional advice before switching on the marker.



ATTACHING A LOADER

Using a 5/32" hex key or your fingers, turn the sprocket screw of the clamping feed tube counter-clockwise (see figure 8A).

Release the clamping lever on the feed tube (see figure 8B) and test to see if your loader can easily be pushed into the top of the feed tube. If the loader cannot easily be pushed into the feed tube, loosen the sprocket screw of the clamping feed tube a little more by turning it counter-clockwise using a 5/32" hex key or your fingers (see figure 8A).

When you have managed to push your loader into the clamping feed tube, close the clamp to secure it firmly in place (see figure 8C). If the loader is loose then you will need to release the clamp, tighten the sprocket screw slightly by turning it clockwise with a 5/32" hex key or your fingers and close the clamp. Repeat this process as necessary to secure your loader in place.

You have now attached a loader to your GEO3.5. Once you have filled your loader and air tank you will then be ready to begin using your GEO3.5.



WARNING!



Do not over tighten the clamping feed tube as this may damage the loader or feed tube itself.

Paintball industry standard eye/face/ear and head protection designed specifically to stop paintballs and meeting ASTM standard F1776 (USA) or CE standard (Europe) must be worn by the user and any person within range during use, assembly, cleaning and maintenance at all times.

THE GAS THROUGH PIPE

There is no need to unscrew or remove the gas pipe assembly during day to day usage of the marker.

Compressed gas is transferred from the frame to the inline regulator via gas pipe assembly (see figure 9A), comprising of a gas pipe section¹ A and pipe nut section B. It is essential that this gas pipe assembly is correctly installed before the marker is supplied with compressed gas.

Before installing the gas pipe assembly, firstly inspect the o-rings on the pipe for any debris or damage (labelled C figure 9A). Cleaning or replacing as necessary. Also inspect the receiver holes in the frame (see figure 9B) and SL4 inline regulator (see figure 9C) for any debris or dirt, cleaning as necessary.

Screw the pipe section into the nut section fully before attempting to install the gas pipe assembly in the marker (see figure 9D). Insert the o-ring end of the pipe nut section into the SL4 regulator swivel (see figure 9E). Rotate the swivel and gas pipe assembly to align the gas pipe section with the gas port in the frame.

Holding the pipe nut section in place inside the SL4 regulator swivel, screw the gas pipe section clockwise to extend it into the frame (see figure 9F). If the gas pipe assembly can slide backwards and forwards, then the pipe is not fully installed and needs to be extended further.

The gas pipe only needs to be removed for maintenance procedures that require removal of the SL4 inline regulator or the frame assembly.

WARNING!



If the gas pipe assembly is not correctly installed high pressure gas will be emitted. DO NOT remove the gas through pipe when the marker is pressurised.

¹ The GEO and EGO gas pipe sections are not interchangeable.



INSTALLING A PRE-SET AIR SYSTEM

WARNING!



- Make sure the marker is turned off with a barrel blocking device installed and that no paintballs are in the marker or loader before installing an air system.
- Compressed air and nitrogen systems can be extremely dangerous if handled or used incorrectly.
- Only use an air system certified for use within the territory of intended use.
- The GEO3.5 cannot be used with CO2. Only USE compressed air or nitrogen.
- Never add any lubricants or greases into the fill adapter of the air system regulator.
- Ensure that all screws are tightened and no parts are loose before installing an air system.
- Do not pressurise the GEO3.5 without the bolt system correctly installed, as high pressure gas will be released.
- Do not install a compressed air system or load paintballs into the GEO3.5 until you feel completely confident with your ability to handle the marker safely and responsibly.
- Always relieve all residual gas pressure from the GEO3.5 before unscrewing the pre-set air system.



Check that the gas through pipe assembly is correctly installed before installing a pre-set air system.

See page 15 for instructions on installing the gas through pipe assembly.



If you are at all unsure about installation of the gas through pipe please contact your nearest service centre.

CONTINUED

Every GEO3.5 comes complete with an Eclipse push on purge system (POPS) which provides a direct connection for a pre-set air system. Before screwing an air system into the POPS ensure that the bonnet is disengaged in its forward position (see figure 10A). If the bonnet is engaged, depress the latch button and slide the bonnet forward.

Check that the POPS retaining screws are tight. If the POPS can be moved on the frame the screws are too loose. Use a 5/32" hex key to tighten the screws.

Screw the pre-set air system into the POPS (see figure 10B) so that the bottle screws in all the way and is tight.

Pull the bonnet backwards allowing the POPS pin to depress the valve pin in the pre-set air system causing the GEO3.5 to become pressurised (providing that there is sufficient air in your tank) (see figure 10C). When the bonnet has been pulled back far enough it engages with the POPS body.^{1,2}

You have now installed a pre-set air system onto your GEO3.5.

¹ High, mid and low pressure output pre-set air systems can be used with the GEO3.5, providing the GEO3.5 has the SL4 inline regulator originally supplied with the marker.

² The force needed to engage the bonnet may vary depending on the output pressure and internal design of the air system being used.



VELOCITY ADJUSTMENT

When using your GEO3.5, you may wish to change the velocity at which your GEO3.5 is firing. This is done by inserting a 1/8" hex key into the adjuster screw at the bottom of your GEO3.5 inline regulator and adjusting it accordingly (see [Figure 11A](#)). By turning this adjuster screw clockwise you decrease the output pressure of the inline regulator and consequently the velocity; by turning the adjuster screw counter-clockwise you increase the output pressure of the inline regulator and consequently the velocity. On the bottom of the inline regulator sleeve there are arrows to illustrate which direction to turn the hex key to make the relevant adjustment.^{1,2,3}

- 1 After each adjustment fire two clearing shots to gain an accurate velocity reading. Never exceed 300fps.
- 2 High, mid and low pressure output pre-set air systems can be used with the GEO3.5, providing the GEO3.5 has the SL4 inline regulator originally supplied with the marker.
- 3 Turning the SL4 adjuster screw in too far will prevent the GEO3.5 from firing.



FIG 11A

SOLENOID FLOW RESTRICTOR

The following section covers direct adjustment of the solenoid valve which should only be used by users with a sound knowledge of the GEO3.5 firing cycle.

Built into the left side of the frame is the solenoid flow restrictor "SFR" (see figure 12A), which controls the exhaust flow from the bolt system through the solenoid valve. By controlling the exhaust flow from the bolt system, the speed of the bolt during the forward stroke can be sped up or slowed down. The SFR can be adjusted using a 5/64" hex key.

The restrictor has a 90° range of adjustment from minimum to maximum flow.

By setting the restrictor to different levels of flow the user can control how the gun performs and feels when firing the marker.

Setting the restrictor to a higher level of flow will allow for higher cycles per second (dependent on the ROF Cap, see page 30). However these higher settings will also reduce the smoothness of the firing cycle compared to setting the restrictor at a lower level of flow.¹

Setting the restrictor to a lower level of flow will increase the smoothness of the firing cycle, however reducing the flow also lowers the cycling rate of the GEO3.5.

WARNING!



Setting the restrictor too low (especially in extreme weather conditions) may result in: low velocity, inconsistent velocity or preventing the bolt from cycling. If this occurs Increase the SFR flow setting.

¹ The restrictor controls the forward stroke of the bolt. As such it has the ability to directly control the velocity of the paintball. It is strongly recommended to chronograph the GEO3.5 after adjusting the restrictor.

The SFR has a minimum and maximum exhaust flow setting.

The maximum exhaust flow setting can be achieved by turning the SFR dial counter-clockwise so it is pointed vertical. This will allow the bolt to move forwards at its fastest possible speed.

The minimum exhaust flow setting can be achieved by turning the SFR dial clockwise so it is pointed horizontal. This setting will apply the greatest restriction on gas exiting the marker, slowing down the bolt forward stroke.

The SFR can be set anywhere in between the minimum and maximum

In the event that you do not want this adjust-ability available on the marker, a blanking plug is provided. This plug has the same effect as having the SFR set to maximum flow.

To install the blanking plug. Push the SFR out of the right side of the frame using a small hex key or pick (see figure 12B), then simply push in the blanking plug making sure it is flush with the frame.




FIG 12A




FIG 12B

UNLOADING THE GEO3.5

Securely attach a barrel blocking device such as the Eclipse Barrel Sock¹ (supplied with the GEO3.5) to the marker as shown in [Figure 13A](#).

Turn off the GEO3.5 electronics by holding down the  button on the back of the frame. When the screen turns off and the marker speaker emits the 'off' tone (if the SOUND parameter is enabled), the marker has been turned off ([see figure 13B](#)).

With the GEO3.5 pointing away from you. De-gas the marker by depressing the POPS latch button allowing the bonnet to slide forward and vent air. Only when the POPS has fully degassed the GEO3.5 marker, unscrew and remove the air system ([see figure 13C](#)).

Open the clamping lever on the feed tube and slacken off the sprocket screw if necessary on the feed tube. Carefully pull the loader out of the feed tube ([see figure 13D](#)).

Looking down the feed tube, check to see if there are any paintballs still in the breach, if there are, turn the marker upside down while still keeping the barrel facing away from any persons within firing range then tip out any paintballs within the breach ([see figure 13E & 13F](#)).

Next remove the barrel blocking device, and unscrew the barrel ([see figure 13G](#)). Remove any paintballs within the barrel. The Eclipse GEO3.5 has now been unloaded and is ready for storage.

WARNING!



Always keep the Eclipse GEO3.5 pointed in a safe direction and ensure all persons within range continue to wear face protection, until marker is completely unloaded and safe.

¹ Instruction on using the Eclipse barrel sock can be found on the Eclipse barrel sock warning label.



STORAGE AND TRANSPORTATION

Your Eclipse GEO3.5 must be clear of all paint and propellant during transportation or storage.

Make sure the Eclipse GEO3.5 marker is off.

Remove the barrel from the marker.

Make sure the marker is clean of any paint residue, dirt and moisture.

Store your Eclipse GEO3.5 in a clean, cool, dry place.

Keep your Eclipse GEO3.5 away from any unauthorized and unsafe users.

It may be a good idea to remove the battery when storing your Eclipse GEO3.5 to prevent unauthorized use.

Protect your Eclipse GEO3.5 from excessive heat during transportation.

When transporting a paintball marker by air, check with the airline regarding their policies on transporting paintball equipment as hold luggage before arriving at the airport.

Observe and obey all local and national laws concerning the transportation of paintball markers. For information concerning any of the laws in your area, contact your nearby law enforcement agency.

When shipping the Eclipse GEO3.5 for any reason, Planet Eclipse recommends using the case in which the marker was originally supplied to protect the marker against rough handling during transport.

CAUTION!



Never carry your Eclipse GEO3.5 un-cased when not on a playing field. The non-playing public and law enforcement personnel may not be able to distinguish between a paintball marker and a real firearm. For your own safety and to protect the image of paintball, always carry the Eclipse GEO3.5 (or any other paintball marker) in a suitable marker case such as the one in which it was supplied.

THE USER INTERFACE

The GEO3.5 has a simple user interface through which all aspects of its electronic control system can be monitored and adjusted by means of the three push-buttons and graphical LCD which comprise the navigation console.

THE RUN SCREEN LAYOUT

The root of the user interface is the run screen which is the screen that is displayed most often when the GEO3.5 is on. The run screen¹ has five display functions and the user can scroll through these functions by repeatedly pressing the  button on the navigation console.

- > Game Timer
- > Shot Counter
- > Peak Rate of Fire Indicator
- > Actual Rate of Fire Indicator
- > SPLASH (marker logo²)

With the exception of the SPLASH, the run screen is vertically divided with the screen function displayed on the left and a series of status icons displayed on the right.

The SPLASH run screen will display the marker logo with a flashing / alternating backlight. The marker is still able to fire when this screen is displayed.

¹ The layout of the run screen is correct at time of printing. However newer versions of the GEO3.5 software may have a different layout of the run screen from what is printed in this manual. You may find some icons have been added or removed entirely. If you are unsure about any icons which do not feature in the manual contact your local dealer/service centre or Planet Eclipse directly.

² The SPLASH graphic can be modified to display custom graphics with the Eclipse E-Portal software sold separately (see page 83 for more information on Eclipse E-Portal).

**BREAK BEAM SENSOR
SYSTEM INDICATOR**

AUX OUT INDICATOR


**TRIGGER DETECTION
INDICATOR**

SOUND INDICATOR

**USER SELECTABLE
DISPLAY OPTION**

LOCK INDICATOR

**BATTERY LEVEL
INDICATOR**



THE BBSS INDICATOR

The BBSS is able to switch itself off in the event of a blockage or contamination preventing it from functioning correctly. In this instance, the BBSS will switch itself back on once the blockage is cleared and the correct operation can be resumed.



BBSS Enabled and ball detected

The GEO3.5 can be fired at the maximum rate of fire determined by the chosen firing mode.



BBSS Fault has been cleared and ball detected

The system has been re-enabled. A ball is detected and the GEO3.5 can be fired at the maximum rate of fire determined by the chosen firing mode.



BBSS Disabled

The GEO3.5 can be fired at a maximum rate of fire as set by the BS OFF ROF parameter (see page 30).



BBSS Enabled in training mode

The BBSS has been over-ridden as the user has selected training mode. As the user has chosen to leave the BBSS on, the achievable rate of fire is limited by the firing mode.

The BBSS indicator on the main screen is used to indicate the eight possible states of the BBSS as follows:



BBSS Enabled no ball detected

The GEO3.5 cannot be fired.



BBSS Fault has been cleared and no ball detected

The system has been re-enabled. No ball is detected so the GEO3.5 cannot be fired. To reset the BBSS icon, use the  button to switch off the BBSS and then back on again.



BBSS Fault detected

The system is disabled. The GEO3.5 can only be fired at a maximum rate of 2 bps less than the maximum rate of fire, up to a maximum of 10 bps.



BBSS Disabled in training mode

The BBSS has been over-ridden as the user has selected training mode. As the user has chosen to turn the BBSS off, the achievable rate of fire is limited by the BS OFF ROF parameter (see page 30).

THE AUX OUT INDICATOR

The auxiliary socket on the GEO3.5 circuit board allows third party products such as loaders or RF transmitters to be interfaced to the GEO3.5.

The AUX out indicator is turned on and off via the AUX OUT parameter (see page 39). There are two possible conditions that can be indicated:



AUX Out enabled

The AUX OUT is enabled. Each time the circuit board detects a valid trigger pull a signal will be sent to the AUX connector on the circuit board.



AUX Out disabled

The AUX OUT is disabled. No signal will be sent to the AUX connector on the circuit board.

THE SOUND INDICATOR

The sound indicator on the run screen is used to convey if the SOUND parameter in the HARDWARE menu (page 37) is switched on or off.

There are two possible conditions that can be indicated:



Sound enabled

The SOUND parameter is enabled. The GEO3.5 will make sounds when switched on and off and when the game timer alarms or times out.



Sound disabled

The SOUND parameter is disabled. The GEO3.5 will not make any sounds.

THE TRIGGER DETECTION INDICATOR

In order for the trigger to be successfully operated it must first be released and then pulled. The Trigger Detection Indicator (TDI) is used to indicate each of the possible trigger states.



OPTO sensor selected, reading 0%

The GEO3.5 is configured to use the OPTO sensor to detect trigger pulls. The OPTO sensor is currently reading 0%, i.e. the trigger is fully released.



OPTO Sensor selected, reading below release point

The GEO3.5 is configured to use the OPTO sensor to detect trigger pulls. The OPTO sensor is currently reading below the OPTO release point, i.e. the trigger is considered 'released'.



OPTO Sensor selected, reading 100%

The GEO3.5 is configured to use the OPTO sensor to detect trigger pulls. The OPTO sensor is currently reading 100%, i.e. the trigger is fully depressed.



OPTO Sensor selected, reading above pull point

The GEO3.5 is configured to use the OPTO sensor to detect trigger pulls. The OPTO sensor is currently reading above the OPTO pull point, i.e. the trigger is considered 'pulled'.



OPTO Sensor selected, reading mid-range

The GEO3.5 is configured to use the OPTO sensor to detect trigger pulls. The OPTO sensor is currently reading somewhere between the OPTO release point and the OPTO pull point, i.e. the trigger is half depressed.



Micro-switch selected, actuated

The GEO3.5 is configured to use the micro-switch to detect trigger pulls. The micro-switch is currently actuated, i.e. the trigger is pulled.



Micro-switch selected, not actuated

The GEO3.5 is configured to use the micro-switch to detect trigger pulls. The micro-switch is not currently actuated, i.e. the trigger is released.

From the factory the GEO3.5 will have the OPTO sensor enabled. The micro-switch can be enabled from the Hardware menu (see page 37).

THE LOCK INDICATOR

The GEO3.5 has a Tournament Lock which prevents the user from making changes to any parameter that affects the way in which the GEO3.5 shoots, without the need for tools.

When the lock is enabled the lock indicator will show a closed padlock .

This feature is necessary in order to make the GEO3.5 legal for tournament play. To enable or disable the tournament lock see Accessing the Menu System on page 27.

When the lock is disabled the lock indicator will show an open padlock .

THE BATTERY LEVEL INDICATOR

The battery level indicator is used to show the state of the battery within the GEO3.5. When the battery is fresh the indicator will show a 'full' battery  and as the battery is drained, so will the indicator show the battery emptying. When the battery reaches a point at which the GEO3.5 will no longer function reliably, the indicator will start to flash. At this point the battery must be changed immediately.

As well as displaying the voltage level of the battery, the indicator also warns if the battery being used has an incorrect voltage to operate the electronics reliably. The icon for a battery with an incorrect voltage output is . If this icon is shown the battery must be replaced immediately.

THE GAME TIMER

When the game timer is shown on the run screen then it can be started by pressing the  button and the timer will start to count down. The game timer can also be configured to start on a trigger press with the start parameter (see page 41).

When the game timer reaches the alarm time the game timer will start to flash and the audible alarm will sound every second, provided that the sound parameter is on.

When the game timer reaches 00:00, GAME OVER will be displayed and the audible alarm will sound continually, provided that the sound parameter is set to 'on'.

To stop the game timer at any time press and hold the  button for 0.5 seconds.

To reset the game timer to its pre-set start time, push and hold the  button for 0.5 second. The game timer will also be reset whenever the GEO3.5 is switched off.




THE SHOT COUNTER

The shot counter will increment every time that the circuit board registers a trigger pull, regardless of whether the shot counter is displayed or not. When the shot counter is displayed on the run screen it can be reset to 0 by pressing and holding the  button for 0.5 seconds.

There is also an optional shot gauge that can be displayed on this run screen.

The gauge counts down from a user adjustable number. To alter the gauge settings see page 40. The gauge is reset whenever the GEO3.5 is switched off or the  button is pressed.

The shot counter does not function when the GEO3.5 is in Training Mode (see page 40).



THE ACTUAL RATE OF FIRE

When the actual ROF is selected for display the run screen will look something like the screen to the right. The value displayed in the top left of the screen represents the number of full cycles completed in a second - the actual rate of fire over that second.

The value below it is the maximum actual rate of fire that has been achieved. The graph below this number shows the actual rates of fire achieved over time where each bar represents the amount of pulls in that second. To reset the maximum, press and hold the  button for 0.5 second.



THE PEAK RATE OF FIRE

When the peak ROF is selected for display the run screen will look something like the screen to the right, which differs from the display of the actual ROF by the inclusion of the indicator 'PK'. The value displayed in the top left of the screen represents the maximum rate of fire that has been recorded over the last second. The value below it is the maximum peak rate of fire that has been achieved.

The graph below this number shows the peak rates of fire achieved over time. To reset this maximum, press and hold the  button for 0.5 seconds.

The peak ROF is typically higher than the actual ROF as it is much easier to fire two shots in quick succession than it is to maintain a string over a longer period of time.




THE MENU SYSTEM

Behind the run screen is a structured menu system comprised of two layers of menus. Each menu contains a number of menu items and each menu item can either be a parameter or a branch to another menu. Branches have an animated graphic on the right of the display, whereas parameters have their current value.

On parameter screens a range bar will be displayed where there is a large scale of adjust-ability in that parameter. The current parameter value is displayed as a box on the range bar which is used to indicate the range of adjust-ability in the parameter value.

At the bottom of the parameter screen the unit for that parameter will be displayed. Some parameters will not have units, such as on or off parameters.

TYPICAL BRANCH




TYPICAL PARAMETER

TYPICAL PARAMETER VALUE

TYPICAL RANGE BAR

TYPICAL PARAMETER UNIT



ACCESSING THE MENU SYSTEM

To access the Main menu from the run screen double-click the  button and the first item on the Main menu will be displayed. Alternatively, push and hold the  button for 2 seconds.

Some of the parameters in the menu system can have a tournament lock applied to them. This lock can be toggled on and off by pressing the tournament lock button on the circuit board (see  in figure 14A).

When trying to select a parameter that is locked, the a **'LOCKED'** message will be briefly displayed.



MOVING AROUND THE MENUS

Press and release the  button to display the next item on the menu. When the last menu item is displayed, pressing the  button will display the first item.

Press and release the  button to display the previous item on the menu. When the first menu item is displayed, pressing the  button will display the last item.

ALTERING PARAMETERS

When the displayed item is a parameter, as indicated by a parameter value on the right of the screen, pressing the  button will activate the EDIT mode which allows the parameter value to be altered. When EDIT mode is active, the black box surrounding the parameter name disappears. There are two types of parameter, numeric parameters and choice parameters.

A numeric parameter has a numeric value whereas a choice parameter is one that has a small number of distinct choices. Altering parameter values is essentially the same for both types of parameter. To alter a numeric parameter, first activate the EDIT mode. Press the  button to increase the parameter value one step at a time. Press and hold the  button to increase the parameter value rapidly. When the value reaches its maximum it will revert to its minimum value. Press the  button to decrease the parameter value one step at a time.

Press and hold the  button to decrease the parameter value rapidly. When the value reaches its minimum it will revert to its maximum value. When the required parameter value is displayed press the  button to accept the value and end the EDIT mode.


To alter a choice parameter, first activate the EDIT mode. Press the  button to display the next choice in the list. When the last choice is displayed, pressing  will display the first choice in the list. Press the  button to display the previous choice in the list. When the first choice is displayed, pressing the  button will display the last choice in the list. When the required choice is displayed press the  button to accept the choice and end the EDIT mode. If the displayed choice is cancel then pressing the  button will end the EDIT mode and restore the parameter to the value that is was prior to editing.

WARNING!




The marker can be fired while navigating all menus and parameters.

Paintball industry standard eye/face/ear and head protection designed specifically to stop paintballs and meeting ASTM standard F1776 (USA) or CE standard (Europe) must be worn by the user and any person within range during use, assembly, cleaning and maintenance at all times.



THE MENU SYSTEM



The Main menu contains both editable parameters and sub-menus which contain editable parameters. Some of these parameters affect the way the GEO3.5 shoots and are tournament locked as standard from the factory.¹

The Main menu also contains the TURN OFF option. Selecting this option will immediately turn off the GEO3.5, preventing it from firing.

Parameters followed by a * are part of the Smart Menu System and will only be displayed depending on your chosen settings. (e.g. The BS ON ROF parameter will only become available if the ROF CAP parameter is set to on).

¹ The layout of the main menu is correct at time of printing. However newer versions of the GEO3.5 software may have a different layout of the main menu, sub-menus and parameters from what is printed in this manual. You may find some parameters have been added or removed entirely. If you are unsure about any parameters which do not feature in the manual contact your local dealer/service centre or Planet Eclipse directly.

PRE-SET MENU

In order to simplify the set up of the GEO3.5 a number of pre-set configurations are available for selection. Choosing one of these pre-sets will cause all of the necessary parameters to be set in such a way as to make the GEO3.5 comply with the rules governing a particular paintball league¹. It is also possible for the user to save up to two pre-set configurations of their own.

LOAD PARAMETER

This parameter is used to load the required pre-set configuration and has the following choices:

- > USER 1: Load a set of custom firing mode parameters that have been previously saved by the user.
- > USER 2: Load a set of custom firing mode parameters that have been previously saved by the user.
- > FACTORY: Reset every parameter to the factory set default. The GEO3.5 leaves the factory set in this way.
- > NPPL: Load a set of parameters that configures the GEO3.5 to comply with the NPPL rules governing firing modes.^{1,2}
- > PSP 10: Load a set of parameters that configures the GEO3.5 to comply with the PSP rules governing firing modes in lower divisions (10bps).^{1,2}
- > PSP 12: Load a set of parameters that configures the GEO3.5 to comply with the PSP rules governing firing modes in higher divisions (12bps).^{1,2}
- > MS10: Load a set of parameters that configures the GEO3.5 to comply with the 2010 Millennium Series rules governing firing modes.^{1,2}
- > CANCEL: Editing is cancelled and the parameter remains unchanged.

SAVE PARAMETER



This parameter is used to save the current set of parameters as a user defined custom pre-set configuration.

This parameter has the following choices:

- > USER 1: Save the current parameters as the pre-set 'USER 1'.
- > USER 2: Save the current parameters as the pre-set 'USER 2'.
- > CANCEL: Editing is cancelled and the parameter remains unchanged.

¹ Some pre-sets and fire modes may only be available in certain countries and on some models of the GEO3.5.

² All pre-sets are correct at time of printing. It is the users responsibility to ensure that the loaded pre-set complies with the event rules the marker is intended to be used in.



FIRE MODE PARAMETER

This parameter is used to select the firing mode of the GEO3.5 and has the following choices:

- > SEMI: This is the default and in this firing mode the GEO3.5 will fire one shot for every trigger pull.
- > RAMP: In this firing mode, the rate of fire is increased above the rate at which the trigger is pulled once certain criteria have been met. These criteria are set by the parameters on the Ramp Setup menu.¹
- > CANCEL: Editing is cancelled and the parameter is unchanged.

¹ Some pre-sets and fire modes may only be available in certain countries and on some models of the GEO3.5.

ROF CAP PARAMETER

The ROF CAP parameter is used to specify whether or not the GEO3.5 should have a limited / capped rate of fire. When the ROF CAP is enabled (and the BBSS is enabled), the maximum achievable rate of fire is set by the BS ON ROF parameter. Choices for the ROF CAP parameter are:

- > OFF: Rate of fire only limited by the loader.
- > ON: Rate of fire limited to the BS ON ROF parameter value.
- > CANCEL: Cancel editing and leave the parameter unchanged.

At the bottom of the parameter screen the unit for that parameter will be displayed. Some parameters will not have units, such as on or off parameters.

BS ON ROF PARAMETER

The BS ON ROF parameter is used to set the maximum achievable rate of fire from the GEO3.5. The value of this parameter can be adjusted between 4.0 and 30.0 balls per second in 0.1bps increments.¹



The BS ON ROF parameter will only be displayed if you have set the ROF CAP parameter to 'ON'.

¹ Always calibrate your GEO3.5 ROF CAP parameters to the local field BPS meter as readings may vary from meter to meter.

BS OFF ROF PARAMETER

The BS OFF ROF parameter is used to control how fast the GEO3.5 cycles when the Break Beam Sensor System is disabled. This parameter can be set between 4.0 and 15.0 balls per second and should always be set to the slowest speed of the loading system in use.¹

¹ Always calibrate your GEO3.5 ROF CAP parameters to the local field BPS meter as readings may vary from meter to meter.



RAMP SET UP MENU

This menu is only available when ramping has been selected with the FIRE Mode parameter and comprises a list of parameters that control the way in which the GEO3.5 ramps, as shown below.

TYPE PARAMETER

This parameter is used to select the ramping style and has the following choices:


- > **STEP:** Step ramping will cause the GEO3.5 to shoot in semi-automatic until a number of trigger pulls, set by SEMI SHOTS, have been made at a minimum pull rate, set by KICK IN. At this point the rate of fire will step up to the maximum rate of fire as set by BS ON ROF (or the maximum loader speed if the ROF CAP parameter is set to off). Ramping is maintained as long as the user continues to pull the trigger at a required rate set by SUSTAIN.
- > **LINEAR:** Linear ramping will cause the GEO3.5 to shoot in semi-automatic until a number of trigger pulls, set by SEMI SHOTS, have been made at a minimum pull rate, set by KICK IN. At this point the rate of fire will equal the rate of trigger pulls increased by the percentage specified by RATE up to a maximum rate of fire as set by BS ON ROF, if the ROF CAP is on. Ramping is maintained as long as the user continues to pull the trigger at a required rate set by SUSTAIN.
- > **CANCEL:** Editing is cancelled and no changes are made to the parameter.

RATE PARAMETER

The parameter is only available when LINEAR ramping is selected and is used to set the percentage increase in rate of fire over rate of trigger pulls.

For example, if the user is pulling the trigger at a rate of 10 pulls per second and the RATE parameter is set to 50% then the rate of fire is 10 plus 50% extra which is 15 balls per second.

This parameter can be set between 0 and 100% in 10% increments.



SEMI SHOTS PARAMETER

The parameter sets the number of shots in semi-automatic that are required at the KICK IN rate before ramping will start. The parameter can be set between 3 and 9 pulls in 1 pull increments.

KICK IN PARAMETER



This parameter sets the minimum rate at which the user has to pull the trigger in order to start ramping. This parameter can be set between 3.3 and 10.0 pulls per second in 0.1 pulls per second increments.

SUSTAIN PARAMETER

Once the GEO3.5 is ramping the user has to continue to pull the trigger at a minimum rate in order to maintain the ramping. This parameter sets this rate and can be between 3.3 and 10.0 pulls per second in 0.1 pulls per second increments.

RESTART PARAMETER

The RESTART parameter defines the amount of time after the last trigger pull during which the ramp can be restarted with a single trigger pull. If a trigger pull occurs after the RESTART time has expired, then the other ramp start conditions have to be met before ramping will restart. This parameter can be set between 0.0 and 1.0 seconds in 0.1 second increments.



TIMING MENU

These parameters all relate to the control of the solenoid valve.

DWELL PARAMETER




The DWELL parameter sets the amount of time that the solenoid is energized and therefore the amount of gas that is released with each shot of the GEO3.5. Setting this parameter too low will result in low velocity shots and/or excessive shot to shot velocity fluctuations. Setting the parameter too high will simply waste gas and make the GEO3.5 louder. The DWELL can be set between 0.0 and 30.0 milliseconds. The factory default setting can normally be reduced after a few thousand shots as the GEO3.5 'beds-in'.

FSD COMP PARAMETER

"First shot drop off" is a reduction in velocity of the first shot fired after an extended period of not firing and is caused by the stiction between dynamic o-rings and the surfaces that they are in contact with. In order to compensate for first shot drop-off this parameter can be set to add extra time to the DWELL parameter for the first shot. This parameter can be set between 0.0 and 5.0 milliseconds.

FSD DLY PARAMETER

The time that has to elapse before the FSD COMP is applied to a shot following a previous shot. This parameter can be set between 00:00 and 04:00 minutes.



FILTER MENU

The parameters on the Filter menu are all used to tune the GEO3.5's software filters which prevent the GEO3.5 from firing unless all of the necessary conditions are met. The factory default settings will be suitable for most set-ups, however certain loader and trigger set-ups may require modification of one or more of these parameters.

DEBOUNCE PARAMETER

The DEBOUNCE parameter is used to combat any trigger bounce that might occur in the GEO3.5 and can be set between level 1 and level 9 in one level increments.


- > LEVEL 9: Level 9 providing the most filtering (least 'bouncy').
- > LEVEL 1: Level 1 providing the least filtering (most 'bouncy').
- > CANCEL: Cancel editing and leave the parameter unchanged.

EMPTY PARAMETER

In order for the BBSS to function correctly it must first detect that the bolt is fully retracted and the breech is empty, and then detect that a paintball is loaded into the breech before the GEO3.5 is allowed to fire. The parameter can be set between 1.0 and 20.0ms in 0.1ms increments.

FULL PARAMETER

Tumbling paintballs can take time to settle in the breech before they can be successfully fired. This parameter is used to set the amount of time that a paintball has to be in the breech before the GEO3.5 is allowed to fire. This parameter can be set between 1.0 and 20 milliseconds in 0.1ms increments.



PULL TM PARAMETER

The PULL TM parameter is used to set the minimum amount of time that the trigger must be pulled before it is recognised as a valid trigger pull. This parameter can be set between 3.0 and 20.0 milliseconds in 0.1ms increments.

RELEASE TM PARAMETER


The RELEASE TM parameter is used to set the minimum amount of time that the trigger must be released before it is recognised as a valid trigger release. This parameter can be set between 3.0 and 25.0 milliseconds in 0.1ms increments.

PULL PT PARAMETER

The PULL PT parameter is only available if OPTO has been selected in the Hardware menu. PULL PT defines the point at which the trigger is considered pulled and is adjustable between 51% and 99% in 1% increments.

RELEASE PT PARAMETER

The RELEASE PT parameter is only available if OPTO has been selected in the Hardware menu. RELEASE PT defines the point at which the trigger is considered released and is adjustable between 1% and 49% in 1% increments.



BASIC TRIGGER FILTER SETUP

95% of trigger bounce problems can be eliminated by utilizing one of the nine fixed DEBOUNCE choices (LEVEL 1-9). In attempting to eliminate trigger bounce it is advisable to try the nine fixed DEBOUNCE choices before attempting any advanced set up of the trigger filters.

ADVANCED TRIGGER FILTER SETUP

In order to optimize the trigger filters it is necessary to have the PULL PT parameter set as high as possible and the RELEASE PT parameter set as low as possible:

1. Select the PULL PT parameter. Observe that the graphical bar rises and falls as the trigger is pulled and released. The actual value of the graphical bar is displayed in the top right of the display.
2. Set the rear stop screw as required, ensuring that the bar is as close to 100% as possible when the trigger is fully depressed against the set screw. It is advisable to allow for some extra travel in the trigger pull once the bar has reached its maximum value.
3. Adjust the PULL PT parameter so that when the trigger is fully depressed the bar settles above the indicator on the left hand side of the screen (see page 35).
4. Select the RELEASE PT parameter. Observe that the graphical bar rises and falls as the trigger is pulled and released. The actual value of the graphical bar is displayed in top right of the display.
5. Set the front stop screw as required, ensuring that the bar is as close to 0% as possible when the trigger is fully released against the set screw. It is advisable to allow for some extra travel in the trigger release once the bar has reached its minimum value.
6. Adjust the RELEASE PT parameter so that when the trigger is fully released the bar settles beneath the indicator on the left hand side of the screen (see page 35).
7. Set the magnet return strength screw and the spring return strength screw as required, making both the spring tension and the return force as strong as possible without compromising the "feel" of the trigger.

HARDWARE MENU

This menu comprises parameters that control low level functionality of the GEO3.5 electronic hardware.



TRIGGER PARAMETER

The GEO3.5 is fitted with a dual trigger pull detection system. A non-contact OPTO-Electronic trigger sensor arrangement is used to detect trigger movement whilst a micro-switch is used to provide a more traditional tactile feedback for the trigger. The TRIGGER parameter is used to select which system is used.

The choices available are as follows:

- > OPTO: Select the OPTO sensor for trigger pull detection.
- > SWITCH: Select the micro-switch for trigger pull detection.
- > CANCEL: Cancel editing and leave the parameter unchanged.

SOLENOID PARAMETER

This parameter controls the amount of power used by the solenoid valve and should normally be left at its default 'LO PWR' setting. Cold weather (sub 0°C/32°F) will cause lubricants to thicken and increase stiction in the marker system which may cause velocity drop-off and/or shot to shot inconsistency. Increasing the solenoid power will often help to eliminate these problems, but will cause more drain on the battery.

The choices available for the parameter are:-

- > LO PWR: Low power solenoid drive.
- > HI PWR: High power solenoid drive.
- > CANCEL: Cancel editing and leave the parameter unchanged.

SOUND PARAMETER

The GEO3.5 board is capable of emitting a variety of sounds to audibly signal when certain functions have been performed including, but not limited to, powering up, powering off, changing the BBSS mode and resetting various counters and timers. This parameter determines if this feature is switched on or off. Switching it on will cause increased drain on the battery.

The choices available for this parameter are:




- > OFF: Sounds switched off.
- > ON: Sounds switched on.
- > CANCEL: Cancel editing and leave the parameter unchanged.

TONES PARAMETER

This parameter determines if the GEO3.5 emits a tone each time any of the push-buttons on the navigation console are activated. As part of the smart menu system the TONES parameter will only be shown in the Hardware menu if the SOUND parameter is switched 'ON'.

The choices available for this parameter are:

- > OFF: Tones switched off.
- > ON: Tones switched on.
- > CANCEL: Cancel editing and leave the parameter unchanged.



BACKLIGHT PARAMETER

This parameter sets the time that the LCD backlight is illuminated after a push-button is pressed. The parameter can be set between 00:00 and 00:20 (20 seconds). If set to 00:00 then the backlight will not be illuminated.

RED LEVEL PARAMETER

This parameter sets the percentage of red light in the LCD backlight and can be set between 0% and 100% in 10% increments.

GRN LEVEL PARAMETER

This parameter sets the percentage of green light in the LCD backlight and can be set between 0% and 100% in 10% increments.

BLU LEVEL PARAMETER

This parameter sets the percentage of blue light in the LCD backlight and can be set between 0% and 100% in 10% increments.



CONTRAST PARAMETER

The parameter sets the contrast level of the LCD. This parameter is adjustable between 0 and 30 in increments of 1.

AUX OUT PARAMETER

This parameter turns on and off the AUX socket on the PCB. The choices available for this parameter are:

- >OFF: AUX socket switched off.
- >ON: AUX socket switched on.
- >CANCEL: Cancel editing and leave the parameter unchanged.




DBL CLICK PARAMETER

This parameter is used to select where double-clicking the  button can be used. The choices available for this parameter are:

- > NONE: Double clicking is disabled entirely. To power up the GEO3.5 and enter the Main Menu the user needs to push and hold the  button.
- > POWER UP: Double clicking only works when powering up the GEO3.5. To enter the Main Menu the user still needs to push and hold the  button.
- > ALL: Double clicking works when powering up the GEO3.5 and entering the Main Menu. Push and hold still works for these procedures as well.
- > CANCEL: Cancel editing and leave the parameter unchanged.

AUTO OFF PARAMETER

This parameter sets the time that has to elapse before the GEO3.5 switches itself off if not used. The parameter can be set between 05:00 and 20:00 minutes.



TRAINING PARAMETER

In training mode the GEO3.5 simulates the firing cycle so that the user may practice pulling the trigger without wasting air and making lots of noise. The BBSS is overridden in order to simulate paintballs entering the breech and the beeper indicates when a shot is fired. Training mode is indicated with a 'T' in the BBSS indicator.

- > OFF: Training mode is disabled and the GEO3.5 functions normally.
- > ON: Training mode is enabled.
- > CANCEL: Cancel editing and leave the parameter unchanged.

SHOT COUNT MENU

This menu is comprised of parameters that control the shot counter.

GAUGE PARAMETER

This parameter allows the user to toggle the gauge graphic on and off in the shot counter Run Screen. The choices for the GAUGE parameter are:

- > OFF: Gauge graphic on the shot counter run screen is disabled.
- > ON: Gauge graphic on the shot counter run screen is enabled.
- > CANCEL: Cancel editing and leave the parameter unchanged.

GAUGE MAX PARAMETER

The gauge max parameter allows the user to set the number the gauge counts down from every time the GEO3.5 is fired. The user can set the gauge from 100 to 2000 in increments of 10.



GAME TIMER MENU

This menu is comprised of parameters that control the operation of the Game Timer.

GAME PARAMETER

This parameter is used to set the Game Time, the time from which the game timer counts down to zero. This parameter can be set between 00:00 and 60:00 minutes in 10 second increments. The factory default is 07:10 (7 minutes 10 seconds).

When the game timer reaches 00:00, GAME OVER will be displayed and the audible alarm will sound continually, provided that the SOUND parameter is set to 'ON'.

ALARM PARAMETER

An alarm condition is generated whenever the Game Timer counts down to the time set by the ALARM parameter. This parameter can be set between 00:00 and 10:00 minutes in 10 second increments.

When the alarm condition is generated the Game Timer will start to flash and the audible alarm will sound every second, provided that the SOUND parameter is set to 'ON'.

START PARAMETER

This parameter is used to select the event which will cause the Game Timer to begin counting down. This parameter has the following choices:

- > **BUTTON:** Pressing the  button will start the Game Timer.
- > **TRIGGER:** Pulling the trigger will start the Game Timer.
- > **CANCEL:** Cancel editing and leave the parameter unchanged.



THE BREAK BEAM SENSOR SYSTEM

Undo the retaining screw for the Break Beam Eye cover on the left hand side of the GEO3.5 using a 5/64" (2mm) hex key (*see figure 15A*).

Remove the eye cover to expose the back of the Break Beam Sensor unit (*see figure 15B*). Using a dry cotton bud, carefully remove any debris, paint or moisture from the back of the sensor unit and from inside the eye cover.

Lift the Break Beam Sensor unit free from the GEO3.5 body and using another dry cotton bud, remove any grease or debris build-up from the front of the sensor unit (*see figure 15C*).



FIG 15A



FIG 15B



FIG 15C

WARNING!



Always de-gas your marker, discharging any stored gas in a safe direction, and remove the barrel, loader, air system and any paintballs to make the marker easier and safer to work on.

Paintball industry standard eye/face/ear and head protection designed specifically to stop paintballs and meeting ASTM standard F1776 (USA) or CE standard (Europe) must be worn by the user and any person within range during use, assembly, cleaning and maintenance at all times.

CONTINUED

Remove the rubber detent and using a dry cotton bud clean the detent and its location point in the GEO3.5 body, replacing the detent if it is damaged (see figure 15D).

Reinsert the detent back into the GEO3.5 body and place the BBSS back into the designated slot in the body (see figure 15E). Ensure that the sensor is face down in the body i.e. looking into the breach.¹

Replace the eye cover and using a 5/64" hex key, replace the retaining screw to hold the eye cover in place (see figure 15F).

Repeat the procedure for the opposite side of the GEO3.5.

You have now cleaned your Break Beam Sensor System.

WARNING!



If you are unsure about performing a maintenance procedure please contact your nearest service centre.

¹ Ensure that the receiver sensor (indicated by a red mark & red heat shrink) is located on the right-hand side of the marker body.

FIG 15D



FIG 15E



FIG 15F



THE SL4 INLINE REGULATOR ASSEMBLY

Unscrew and remove the gas pipe assembly from the SL4 inline regulator (see figure 16A). See page 15 for more information on removing the gas pipe assembly.

Grip the SL4 inline regulator tightly through the rubber sleeve and unscrew the SL4 inline regulator from the GEO3.5 body (see figure 16B). Pull the foregrip crown down to free it from the GEO3.5 body (see figure 16C).

Inspect the o-ring at the top of the threads on the FRM for damage (labelled A figure 16D). Replace and re-lubricate as necessary.¹

Tip both the piston and spring out of the top of the inline regulator (see figure 16E).

Insert a 1/8" hex key into the adjuster screw assembly in the bottom of the inline regulator, turn the adjuster screw clockwise through the inline regulator body (see figure 16F & 16G), and push the adjuster assembly out of the top of the inline regulator body.²

Thoroughly clean the O11 NBR70 o-rings that sits on the outside of the adjuster assembly, then re-lubricate with Eclipse Grease (see figure 16H).¹

Using a dry cotton bud, clean the internal 008 NBR70 o-ring that sits inside the top section of the adjuster top. Then using a small hex key gently apply Eclipse Grease to the o-ring (see figure 16I).¹



WARNING!



Always de-gas your marker, discharging any stored gas in a safe direction, and remove the barrel, loader, air system and any paintballs to make the marker easier and safer to work on.

¹ If any o-rings are damaged then replace them. Extra o-rings are available in parts kits available at www.planeteclipse.com.

² The adjuster screw can only be removed by turning it upwards through the bottom section of the inline regulator. The regulator will be damaged if the adjuster screw is removed incorrectly.

CONTINUED

Inspect the internal sealing surfaces of the regulator body, removing any dirt or debris with a cotton bud (see figure 16J).

Re-install the adjuster assembly into the inline regulator body threaded end first. Apply light pressure to the top of the adjuster, while using a 1/8" hex turn the adjuster screw counter-clockwise until it stops at the base of the inline regulator body (see figure 16K).

Take the piston, inspect for damage and clean the 14x2 NBR70 o-ring at the top. Re-lubricate it with a light application of Eclipse Grease (See Figure 16I). Place the inline regulator spring over the piston, then insert the piston and spring into the top of the inline regulator body (see figure 16M).¹

To replace the foregrip crown, push the crown up onto the body until the FRM threads and body plug are covered (see figure 16N).

Re-attach the inline regulator to the GEO3.5 FRM (see figure 16O), then re-connect the gas pipe fitting (see page 15).

Basic cleaning of the SL4 inline regulator is complete.

Reset the input pressure to the factory default before supplying the GEO3.5 with compressed air.

WARNING!



If you are unsure about performing a maintenance procedure please contact your nearest service centre.

¹ If any o-rings are damaged then replace them. Extra o-rings are available in parts kits available at www.planeteclipse.com.



ADVANCED INLINE REGULATOR MAINTENANCE

This procedure is only required if you are fixing a supercharging SL4 inline regulator (common symptoms of supercharging are a very high velocity first shot and/or large variances in shot to shot consistency).

Place a 3/32" hex key through the adjuster top (see figure 17A), then insert a 1/8" hex key into the bottom of the adjuster screw and carefully turn it counter-clockwise until the two parts begin to unscrew freely (see figure 17B). With your fingers fully unscrew the two parts taking care not to lose any of the internal components (see figure 17C).

Inside the adjuster screw you will find a regulator seal, purge poppet and spring (purge poppet assembly) (see figure 17D). Inspect and clean the regulator seal, turning it over if one side appears excessively worn or damaged or replace if necessary. Inspect and clean the purge poppet or replace if necessary.

Place the purge poppet and attached spring in the central hole in the regulator seal, then insert these parts into the adjuster screw (see figure 17E). Ensure it is re-installed correctly, failure to do so may seriously damage the GEO3.5 solenoid.

With the regulator seal, purge valve and spring installed back into the adjuster screw, replace the adjuster top (see figure 17F). Screw the two parts tightly together using 1/8" and 3/32" hex keys. Refer to the 'SL4 Inline Regulator Assembly' section on pages 44-45 to re-assemble the SL4 inline regulator.

WARNING!



Always de-gas your marker, discharging any stored gas in a safe direction, and remove the barrel, loader, air system and any paintballs to make the marker easier and safer to work on.

If you are unsure about performing a maintenance procedure please contact your nearest service centre.



CLEANING THE BODY FILTER

Remove the inline regulator as covered on page 44. Turn the GEO3.5 upside down to reveal the body filter inside the body (see figure 18A).

Using a 5/64" hex key unscrew and remove the retaining screw (see figure 18B).

Then remove the body filter (see figure 18C).

Inspect and clean the body filter. If the filter is very dirty replace with a new filter.

Insert the filter¹ into the FRM on the GEO3.5 body, ensuring the hole in the filter lines up with the threads in the body (see figure 18D).

Using a 5/64" hex key, replace the retaining screw. DO NOT over tighten the retaining screw as this may result in the filter being crushed between the screw and GEO3.5 body (see figure 18E).

Re-attach the inline regulator to the GEO3.5.

If after cleaning the GEO3.5 is still experiencing slow purge and low velocity issues the filter may need replacing.

WARNING!



Always de-gas your marker, discharging any stored gas in a safe direction, and remove the barrel, loader, air system and any paintballs to make the marker easier and safer to work on.

If you are unsure about performing a maintenance procedure please contact your nearest service centre.

¹ If the filter has only been cleaned and not replaced with a new one, ensure the filter is inserted back into the body facing the same way it was removed. This will prevent any dirt embedded in the filter being blow into the bolt system of the marker when supplied with compressed air.



FIG 18A



FIG 18B



FIG 18C



FIG 18D



FIG 18E

MAINTAINING THE BOLT SYSTEM

The GEO3.5 comes with two bolts. A soft nosed ST3 Bolt and an all metal ST Bolt (see page 72).

To install the ST bolt follow the maintenance procedure below, swapping over the bolts.

After installation, re-chronograph the GEO3.5 and adjust the SL4 inline regulator accordingly.

Push the bolt bonnet up, unlocking the bolt system (see figure 19A). With the bolt bonnet disengaged pull the entire bolt system out of the GEO3.5 body (see figure 19B).

Unscrew and separate the propshaft and bolt can sub-assemblies (see figure 19C). Then push the bolt out of the back of the bolt can.

You should now have the following parts from the marker body: the bolt part **A**, the bolt can part **B** and the prop shaft assembly **C** (see figure 19D).

Take the bolt can and having cleaned off any old grease, paint or debris, apply a small amount of Eclipse Grease to the internal o-ring and the two external o-rings (see figure 19E & 19F)¹.

WARNING!



Always de-gas your marker, discharging any stored gas in a safe direction, and remove the barrel, loader, air system and any paintballs to make the marker easier and safer to work on.

Always check the shooting velocity of the GEO3.5 with a chronograph before using the marker.



CONTINUED

Smear a light coat of Eclipse Grease onto the smooth internal bore of the bolt can from the rear (see figure 19G).

Take the prop shaft and having cleaned off any old grease, paint or debris, apply Eclipse Grease to the large rear o-ring (see figure 19H) and also to the 14x2 o-ring near the front of the prop shaft (see figure 19I).

Take the bolt and having cleaned off any old grease, paint or debris, examine the rubber bolt tip for any signs of damage (see figure 19J), replacing if necessary.

Apply a light film of Eclipse Grease to cover the front end of the bolt and also the internal rear bore of the bolt (see figure 19K & 19L). Apply a coat of Eclipse Grease to the rear external Bolt o-ring near the centre of the bolt (see figure 19M).

Remove excess Eclipse Grease by wiping off with finger. Aim to apply only a very thin film of grease to the components maintained, as excess grease bolt can cause poor performance.

Slide the bolt onto the prop shaft (see figure 19N) and slide the bolt can over the bolt and screw onto the prop shaft back cap (see figure 19O). The can and propshaft parts should meet when fully screwed together.

Finally wipe any excess grease off the bolt tip and insert the complete bolt assembly into the marker body.

With the bolt assembly full inserted into the body, push the bolt bonnet down into the body. The bolt bonnet should match the body profile at the rear when correctly located (see figure 19P).

WARNING!



If you are unsure about performing a maintenance procedure please contact your nearest service centre.

1 Remove any excess blobs of Eclipse Grease from the inside and outside of the bolt can.



ADVANCED BOLT SYSTEM MAINTENANCE

This procedure is only required if you are maintaining the rear section of the prop shaft assembly due to a leak coming from within the bolt bonnet sub assembly or from the front of the bolt. After maintaining the front 14x2 propshaft o-ring and O17 internal can o-ring.

Firstly remove the bolt system assembly, then separate the bolt can and prop shaft assemblies as detailed on pages 48-49.

Push down on the split in the delrin retaining ring and pull the retaining ring out of the prop shaft back cap (see figure 20A).

Remove the prop shaft from the back cap, taking care not to lose the prop shaft spring, plunger or plunger o-ring.

Check the 14x2 o-ring at the back of the prop shaft, and clean or replace then re-lubricate with Eclipse Grease as necessary. Check the rear bumper for signs of wear, replace as necessary (see figure 20B).

Check the 5x1 o-ring seated on the plunger, clean or replace as necessary.

Place the plunger and spring within the propshaft, with plunger dome pointing away from the prop shaft (see figure 20C).

Replace the back cap over the rear of the prop shaft, pushing the prop shaft back into the back cap (see figure 20D)¹.

Compress the retaining ring (see figure 20E) and push the retaining ring into the back cap. The retaining ring needs to sit in its designated groove in the back cap. If the prop shaft can be pulled out of the back cap then the retaining ring has not seated correctly.

WARNING!



Always de-gas your marker, discharging any stored gas in a safe direction, and remove the barrel, loader, air system and any paintballs to make the marker easier and safer to work on.

¹ If any o-rings or the bumper are damaged then replace them. Extra o-rings and bumpers are available in parts kits available at www.planeteclipse.com.



FIG 20A



FIG 20B



FIG 20C



FIG 20D



FIG 20E



FIG 20F

REMOVING THE FRAME

Removal of the frame is required for access to the solenoid assembly, trigger bearing carrier assembly and Break Beam Sensor System wires if maintenance on either is required.

Disconnect any hosing and unscrew the inline regulator from the Front Regulator Mount (FRM) as detailed in the 'Cleaning the inline regulator' section of this Maintenance Guide.

Using a 5/64" hex key, remove the four screws that attach the GEO3.5 rubber grips to the GEO3.5 frame (see figure 21A).

Unplug the solenoid and the Break Beam Sensor System wiring harnesses from their respective ports on the GEO3.5 circuit board (see figure 21B).

Using a 1/8" hex key, unscrew but DO NOT REMOVE the front frame screw located under the foregrip crown (see figure 21C).

Using the short arm of a 1/8" hex key, loosen the rear frame screw 2-3 full turns (see figure 21D).

Slide the frame backwards approximately half an inch so that the rear frame screw disengages from the frame and remove the frame from the GEO3.5 body taking care not to damage any wires (see figure 21E).

You have now removed your GEO3.5 frame from the GEO3.5 body.

WARNING!



Always de-gas your marker, discharging any stored gas in a safe direction, and remove the barrel, loader, air system and any paintballs to make the marker easier and safer to work on.

If you are unsure about performing a maintenance procedure please contact your nearest service centre.



ATTACHING THE FRAME

To install the frame, firstly check the SFR seal is correctly located in the top of the frame (see figure 22A), then carefully thread the solenoid and the Break Beam Sensor System wiring harnesses through the access hole in the top of the frame and line the frame up so that the rear frame screw sits in the access hole (see figure 22B).

Be careful not to trap or pinch the BBSS or solenoid wires between the body and frame.

Slide the frame forward so that it sits completely flush with the GEO3.5 body and using the short arm of a 1/8" hex key, tighten the rear frame screw into place (see figure 22C). Check that no wires are trapped before tightening down the rear frame screw.

Once the rear frame screw is secure, insert a 1/8" hex key into the front frame screw hole in the foregrip crown and tighten the front screw into place (see figure 22D).

Connect the solenoid and Break Beam Sensor System wiring harnesses to their respective ports on the GEO3.5 circuit board and (see figure 22E). Adjust the wires so that they sit neatly in the grip frame and ensure that the wires do not obstruct either the micro-switch or the OPTO sensor (see figure 22F).

Attach the GEO3.5 rubber grips to the frame using a 5/64" hex key to replace the four grip screws (see figure 22G).

Screw the inline regulator back into the Front Regulator Mount and connect any hosing that was disconnected earlier (see figure 22H).

You have now re-installed the frame onto the GEO3.5.



WARNING!



Always de-gas your marker, discharging any stored gas in a safe direction, and remove the barrel, loader, air system and any paintballs to make the marker easier and safer to work on.

If you are unsure about performing a maintenance procedure please contact your nearest service centre.

MAINTAINING THE SFR

The stages below on SFR maintenance do not require the frame to be removed, and can be followed for SFR removal/ blanking plug installation.

Using a small hex key push the SFR body out of the left side of the frame (see figure 23A).

Inspect and clean the SFR body and o-rings, making sure the hole through the centre of the SFR body is free of paint or debris (see figure 23B).

Lastly make sure the pocket in the frame that houses the SFR and the exhaust port below are clean (see figure 23C).

Next, insert the SFR body into the frame as shown in figure 23D. Make sure the dial sits flush with the surface of the frame (see figure 23E).

This last stage of maintenance requires the frame to be removed. It is only need if the SFR is having little or no effect.

In the top of the frame locate and remove the SFR seal (see figure 23F). Inspect and clean the seal, replacing if damaged or heavily worn.

Reinsert the SFR seal into the top of the frame, making sure the contoured face is exposed (see figure 23G).

WARNING!



Always de-gas your marker, discharging any stored gas in a safe direction, and remove the barrel, loader, air system and any paintballs to make the marker easier and safer to work on.

If you are unsure about performing a maintenance procedure please contact your nearest service centre.



THE TRIGGER ASSEMBLY

Having removed the frame completely from the GEO3.5 body (see page 51). Unscrew the two M2.5x5 retaining screws which hold the bearing carrier in the frame (see figure 24A).

Gently lift the bearing carrier and trigger assembly free from the frame taking care not to damage the micro-switch or the OPTO sensors (see figure 24B).

Remove the trigger spring from the bearing carrier, removing any paint or moisture (see figure 24C).

Using a 1/16" hex key, loosen the trigger pin retaining set screw from the back of the trigger (see figure 24D).

Use a small hex key to push the trigger pin out of the bearing carrier from one side (see figure 24E), then remove the bearing carrier from the trigger (see figure 24F).

Clean the trigger and bearing carrier thoroughly and also clean the space within the frame that the trigger sits in.



WARNING!



Always de-gas your marker, discharging any stored gas in a safe direction, and remove the barrel, loader, air system and any paintballs to make the marker easier and safer to work on.

CONTINUED

Position the trigger so that the hole through the trigger lines up with the holes in the bearing carrier, slide the trigger pin into place (see figure 24G).

Gently lower the trigger assembly and bearing carrier into the frame, taking care not to damage the micro-switch or the OPTO sensor, and ensuring that the trigger is positioned correctly (see figure 24H).

Using a 5/64" hex key screw the right side M2.5x5 retaining screw into place but do not fully tighten it into place (see figure 24I).

Ensure the trigger moves freely within the frame, then using a 1/16" hex key tighten down the trigger pin retaining set screw.

Place the trigger spring over the bearing carrier in its designated groove, align the hole in the trigger spring with the front/left hole in the bearing carrier, then screw the retaining screw into the frame. Tighten both screws with a 5/64" hex key (see figure 24J).

DO NOT over-tighten the retaining screws. Doing so may damage the trigger spring and threads in the frame.

You have now stripped and cleaned your GEO3.5 trigger assembly.

WARNING!



If you are unsure about performing a maintenance procedure please contact your nearest service centre.



FIG 24G



FIG 24H



FIG 24I



FIG 24J

SOLENOID ASSEMBLY

IMPORTANT!

The GEO3.5 solenoid assembly contains two sub-assemblies, the solenoid valve and the solenoid manifold. Removal of the solenoid valve is required to access the solenoid manifold for servicing. The solenoid valve itself (see figure 25A) is a non-serviceable item. Any attempt to strip or service the solenoid valve will immediately void the GEO3.5 warranty. If you experience any issue with the GEO3.5 solenoid valve then please contact your Eclipse Service Centre. See page 66 for Eclipse Service Centre details.

With the frame separated from the GEO3.5 body and the solenoid and BBSS wires unplugged from the circuit board (see page 51) use a 5/64" hex key to undo and remove the two screws that hold the solenoid assembly onto the GEO3.5 body (see figure 25B).

Firstly remove the solenoid valve from the body, this will expose the solenoid manifold which sits partially inside the GEO3.5 body (see figure 25C).

Carefully pull the solenoid manifold out from the GEO3.5 body, exposing the gas transfer holes which lead to the bolt assembly (see figure 25D). The solenoid gasket may still be attached to the body, if this is the case, carefully peel the gasket off the body and place to one side.

With the solenoid assembly completely removed from the GEO3.5 body, the bottom of the GEO3.5 body should now resemble figure 25E. Ensure that the air transfer holes in the bottom of the body are free from contamination from any dirt, debris, paint or moisture and clear away any excess grease if it appears to be blocking any of the transfer holes.



WARNING!



Always de-gas your marker, discharging any stored gas in a safe direction, and remove the barrel, loader, air system and any paintballs to make the marker easier and safer to work on.

CONTINUED

Check the underside of the solenoid valve to ensure that it is free from damage or debris (see figure 25F).

The solenoid manifold has two gaskets, the top gasket **A** and the bottom gasket **B** as illustrated in figure 25G. Carefully remove both gaskets from the solenoid manifold. Inspect and clean the top and bottom gaskets and the solenoid manifold, replacing any damaged components.¹

Using a small size hex key or flat headed screw driver, gently push the poppet and cap out of the solenoid manifold (see figure 25H). Inspect and clean the poppet, paying particular attention to the condition front face and o-rings (see figure 25I). If either is damaged or worn, the poppet will need replacing.

Reinsert the poppet into the solenoid manifold in the orientation shown in figure 25J. Then insert the cap, ensuring that it is firmly held in the solenoid manifold.

Replace the top and bottom gaskets into their respective grooves in the solenoid manifold as shown in figures 25K and 25L. Applying a small amount of Eclipse Grease to the surface of the solenoid manifold and gaskets.



WARNING!



If you are unsure about performing a maintenance procedure please contact your nearest service centre.

¹ If the solenoid manifold is damaged remember to remove the poppet and cap before disposing of the solenoid manifold.

CONTINUED

Lastly inspect and clean the large solenoid gasket, replacing if damaged (see figure 25M).

Apply a small amount of grease to the outer most groove surrounding the solenoid manifold pocket in the GEO3.5 body. Then making sure the top solenoid manifold gasket lies flat in the solenoid manifold, insert the solenoid manifold back into the GEO3.5 body (see figure 25N).

Next place the solenoid gasket over the solenoid manifold ensuring that the gasket is secure in its groove in the GEO3.5 body (see figure 25O). Make sure that the bottom solenoid manifold gasket is flat in its groove in the solenoid manifold.

Place the solenoid valve over the solenoid manifold (see figure 25P), making sure the location holes line up with the threads in the GEO3.5 body (see figure 25Q).

Replace the retaining screws which hold the solenoid onto the GEO3.5 using a 5/64" hex key (see figure 25R). DO NOT over tighten screws in the solenoid assembly.

Maintenance of the solenoid assembly is complete.



WARNING!



If you are unsure about performing a maintenance procedure please contact your nearest service centre.

THE PUSH ON PURGE SYSTEM (POPS)

There is no need to remove the POPS from the GEO3.5 frame for general maintenance. IF the POPS is removed, ensure the o-ring is correctly seated before POPS re-attachment.

Fully depress the latch button then slide the bonnet forward while continuing to depress latch button (see figure 26A).

When the bonnet is in the forward position (see figure 26B) remove the latch button and spring from the bonnet (see figure 26C) then slide the bonnet off the POPS body (see figure 26D). Be careful not to lose the spring.

Carefully slide the push rod out from either side of the POPS body, taking care not to lose the two o-rings on the push rod (see figure 26E).

Clean off any dirt, debris or moisture from the bonnet, the POPS body and the latch button (see figure 26F).

Remove the POPS insert assembly using a 5/32" hex key (see figure 26G). Remove the POPS pin from the POPS Insert.

Clean and check the condition of the 007 NBR70 o-ring on the outside of the POPS insert, replacing as necessary (see figure 26H).



WARNING!



Always de-gas your marker, discharging any stored gas in a safe direction, and remove the barrel, loader, air system and any paintballs to make the marker easier and safer to work on.

CONTINUED

Clean and check the condition of the single internal 005 NBR90 o-ring in the front of the POPS insert, replace if necessary (see figure 26I). Lubricate this o-ring liberally using Eclipse Grease.

Lubricate the narrow end of the POPS pin with a smear of Eclipse Grease and push the pin, narrow end first, into the POPS insert and pokes through to the front (see figures 26J& 26K).

Screw the POPS insert back into the POPS body ensuring that the o-ring end goes in first (see figure 26G).

Replace the push rod into its designated slot (see figure 26L), then slide a 004 NBR70 o-rings on both ends of the push rod. Make sure the push rod is centred in the POPS body (see figure 26M).

Slide the bonnet over the POPS body and align the hole on the bonnet with the front hole on the POPS body (see figure 26N).

Ensure the spring is on the latch button then slide them both into the POPS body through the hole in the bonnet, spring end first, making sure the latch button pokes out the right side of the bonnet (see figure 26O).

Push the button down as far as it will go, then (while still holding down the button) slide the bonnet back until the button engages with the POPS body and cannot slide into the forward position (see figure 26P).

You have now successfully cleaned and maintained the Push On Purge System.



WARNING!



If you are unsure about performing a maintenance procedure please contact your nearest service centre.

FAULT FINDING

The fault finding guide covers common symptoms, causes and solutions that are likely to be encountered by the average user.

If an issue with the GEO3.5 cannot be solved using the fault finding guide, contact your nearest Eclipse Service Centre for assistance.

<i>SYMPTOM</i>	<i>POSSIBLE CAUSE</i>	<i>SOLUTION</i>
Although a fresh battery has been fitted, the GEO3.5 will not switch on	The battery has been fitted incorrectly	Fit the battery correctly with the positive terminal nearest to the side of the frame
	The battery has drained on the shelf	Replace with another fresh battery
	The battery terminals are not making proper contact with the battery	Remove the battery, gently bend the terminals towards where the battery will sit and then replace the battery
The battery does not seem to last very long	The battery type is of a low quality	Use an alkaline or metal hydride battery Do not use a low quality or rechargeable battery
The GEO3.5 does not fire	The POPS is not engaged	Engage the POPS fully
	Solenoid Flow Restrictor (SFR) set too low	Increase the flow through the SFR
	The SFR assembly is blocked	Strip and clean the SFR assembly
	Battery quality or level of charge is very low	Install new high quality battery
	Battery is flat	Install new high quality battery
	Training mode is enabled	Disable training mode
	Trigger and trigger detection method are set up incorrectly	Set up the trigger correctly (refer to "Setting the trigger" section)
	Trigger detection system is blocked	Remove any wires or debris from the trigger detection system
	Solenoid assembly is not plugged into GEO3.5 PCB correctly	Plug solenoid assembly plug into the solenoid port on the GEO3.5 PCB
The break beam sensor system is enabled but there are no paintballs in the breech	Fill the loader with paint/ turn on loader	

<i>SYMPTOM</i>	<i>POSSIBLE CAUSE</i>	<i>SOLUTION</i>
The GEO3.5 does not fire	The micro-switch is not being activated	Adjust the micro-switch activation screw accordingly
	The micro-switch is damaged	Replace the circuit board
	The PCB is damaged	
	The solenoid valve is damaged	Replace the solenoid valve
	The solenoid valve wires are damaged	
The GEO3.5 does not cycle fully	The bolt assembly is dirty or incorrectly lubricated	Clean, re-lubricate and replace the o-rings on the bolt as necessary
	The Dwell parameter is set too low	Increase the Dwell parameter
	A sticky or faulty poppet in the solenoid manifold	Check the poppet, clean and replace as necessary
The GEO3.5 is inconsistent	The Dwell parameter is set too low	Increase the Dwell parameter
	The Solenoid Flow Restrictor (SFR) is set too low	Increase the flow through the SFR
	Using poor quality paintballs	Use better quality paintballs
	A poor paintball to barrel bore match	Use a better paintball to barrel bore size match
	The inline regulator is supercharging	Strip and clean inline regulator
	Dirty body filter	Strip and clean the body filter
	Poor / inconsistent air supply into POPS	Use a good quality pre-set air system
The GEO3.5 is inefficient	The Dwell is excessively high	Reduce the Dwell
The GEO3.5 has low rate of fire	The Solenoid Flow Restrictor is set too low	Increase the amount of flow on the SFR
	The force setting on the loader is too low	Adjust the loader force feed setting

<i>SYMPTOM</i>	<i>POSSIBLE CAUSE</i>	<i>SOLUTION</i>
The GEO3.5 de-gasses very slowly	The body filter is blocked / damaged	Clean the body filter and inspect for damage Replace if damaged
The GEO3.5 leaks from the solenoid assembly	Check that the three solenoid gaskets are intact and seated in their designated pockets both in and around the solenoid manifold	Replace any of the solenoid gaskets if they are damaged
	GEO3.5 solenoid assembly is over-pressurising	Check the inline regulator output pressure and consequent velocity. Adjust accordingly
		Strip and clean the SL4 inline regulator. Replacing the seals as necessary
	Debris on / damage to poppet	Clean / replace the poppet
GEO3.5 leaks down the barrel	Damaged GEO3.5 solenoid valve	Replace the GEO3.5 solenoid valve
	Front or rear prop shaft 14 x2 NBR 70 o-rings are damaged, dirty or dry	Replace, clean and lubricate 14 x 2 NBR 70 o-rings on prop shaft
GEO3.5 leaks down the barrel	Internal 017 NBR 70 o-ring and external 020 NBR 70 o-rings on bolt can are damaged, dry or dirty	Replace, clean and lubricate 017 NBR 70 o-ring and 020 NBR 70 o-rings on the bolt can
	The bolt is stuck in a forward position	Push the bolt backwards
Gas vents quickly down the barrel as soon as the GEO3.5 is gassed up	Main prop shaft 014x2 o-ring is damaged or an incorrect size	Replace with a new 014x2 size o-ring
	The loader has too high a force feed setting	Adjust the loader to a lower force feed setting
The GEO3.5 is chopping or trapping paint	Poor quality paintballs	Use better quality paintballs
	The break beam sensor system is switched off	Switch on the break beam sensor system
	The bolt is dirty causing the incorrect detection of paintballs	Clean the bolt and breach

<i>SYMPTOM</i>	<i>POSSIBLE CAUSE</i>	<i>SOLUTION</i>
The GEO3.5 is chopping or trapping paint	The break beam sensor system is dirty causing the incorrect detection of paintballs	Clean the break beam sensor system
	Incorrectly seated rubber bolt tip	Re-seat the rubber bolt tip
	Damaged rubber bolt tip	Replace the rubber bolt tip
The GEO3.5 has low velocity on the first shot	The FSDO parameters are set too low to overcome o-ring stiction	Adjust FSD COMP and FSD DLY parameters
The GEO3.5 has high velocity on the first shot	The FSDO parameters are set too high	Adjust FSD COMP and FSD DLY parameters
	The inline regulator output pressure is creeping	Strip, clean and maintain inline regulator Replace inline regulator Piston if necessary
GEO3.5 has velocity drop-off during rapid fire	The battery is poor quality or has insufficient power	Use an Alkaline or metal hydride battery. Do not use a low quality or rechargeable battery
	The Solenoid Flow Restrictor (SFR) is set too low	Increase the flow through the SFR
	Air system/regulator does not flow fast enough to keep up	Try another air system/regulator and replace as necessary
	Sticky/over lubricated o-rings in bolt assembly	Clean, re-lubricate and replace o-rings on bolt assembly as necessary
	Blocked body filter	Clean / replace the body filter as necessary
	Solenoid poppet is sticking from debris or too much grease	Clean and lightly grease the solenoid poppet
	Poorly maintained inline regulator	Strip, lubricate and rebuild inline regulator
Constant low velocity	The SL4 inline regulator is set too low	Increase the output pressure of the SL4 inline regulator

<i>SYMPTOM</i>	<i>POSSIBLE CAUSE</i>	<i>SOLUTION</i>
GEO3.5 trigger is very "bouncy"	Incorrect filter settings	Check that your trigger filter and de-bounce settings suit your trigger set-up
The break beam sensor system does not appear to be reading correctly	The break beam sensor system is dirty	Clean the break beam sensor system
The break beam sensor system is not reading at all	The break beam sensors are the wrong way around	Check that the red receiver is on the right-hand side of the breach
	There is a broken wire or contact, or a short circuit on either of the break beam sensor cables	Check the plug on the cables
		Check for cuts or pinches in the sensor cables
	Either break beam sensor is back to front	Check that the sensors face each other when installed
Two or more balls are being fed into the breach	The rubber detents are broken / missing	Change the rubber finger detents
	Loader feed force is set too high	Reduce the feed force on the loader
The break beam sensor system turns itself off after firing	The eye is dirty	Clean the eyes
	The eye is faulty	Replace the eyes
	The eye is out of place	Re-install the eyes then check the alignment
When the GEO3.5 powers up, the right hand side of the screen is not displayed and the marker will not fire	The trigger is permanently depressed	Adjust the trigger until the selected trigger detection method is activated when the trigger is released

The fault finding guide covers common symptoms, causes and solutions that are likely to be encountered by the average user. If a issue with the GEO3.5 cannot be solved using the fault finding guide, contact your nearest Eclipse Service Centre for assistance.

ECLIPSE SERVICE CENTRES

Are you unsure of where to send your GEO3.5 to be repaired or serviced? If your local Eclipse dealer can't assist you, why not contact your nearest certified Eclipse Service Centre and arrange for them to undertake any work that you require.

A map listing all of our Service Centres and their contact details can be found in the SUPPORT section of the Planet Eclipse web site at:

WWW.PLANETECLIPSE.COM/SITE/SERVICE-CENTRES

For any Technical Support or Customer Service enquiries please ensure that you have registered your product (where applicable) using the Warranty Card in this manual or online prior to contacting the appropriate representative in your region.

PLANET ECLIPSE
AIR SOFT GAMES

NEWS CONTACT SUPPORT DEALER LOCATOR ECLIPSE TV COMMUNITY TEAMS DOWNLOADS WEB SITES

ECLIPSE SERVICE CENTRES

Planet HD Master Service Centre Authorized Service Centre

Map Navigation

Find your local Eclipse Service Center by navigating our Google Map. Use the + and - to zoom in and out of the desired location. Click and drag or use the navigation arrows on the map to find your location. Would you like to see a [larger version?](#)

Sending in a Marker?

Before sending in your marker for servicing please follow these simple steps to ensure effective & timely service.

1. Download the official [Eclipse Cover Letter](#)
2. Complete the "Name" field with your FULL address (including apt. to include your apartment code)
3. Complete the "Address" field with your FULL address (including apt. to include your apartment code)
4. Complete the "Warranty Number" field with the WSN (Warranty Number) that you have been given by your Eclipse Service Center. If you do not have the WSN between the Eclipse Service Card that you will be sending the marker for in order to obtain it.
5. Complete the "Product/Accessory" field with details of each product that you are sending in, including the MODEL name (optional) and SERIAL NUMBER (where applicable)
6. Complete the "Inventory of assets" field with details of the items that you are experiencing with each of the above products
7. Confirm that the above products are registered for warranty purposes by ticking the relevant box
8. Complete the Contact fields providing your CoM/Model number and Email address
9. Sign and print your name at the bottom of the document
10. Print the completed document & include the completed Covering Letter with the products that are sent in to the Eclipse Service Center.

GET HELP	PAGES	COMMUNITY	SITES
Contact	Publics	ETV - Video Channel	Buy Eclipse Online (shop)
Print & Dealer	Company	Facebook	Ego™ Website
Get Support	Shipping	Twitter	Evo 3 Website
Print & Service Centre	Product Return Guide	Forum	Eclipse™ Website
Mail list sign-up!	PAINTBALL MARKERS	Eclipse Ring	Custom Website
Contact	Disc	Forums	Planet Store
			PETA

PSA
Planet Eclipse
© Copyright Planet Eclipse Ltd - New Lease A Deal v1.0 (2.0 Jan 2011) (Eclipse eclipse 10/2010)

OPERATIONAL OVERVIEW

Below is a brief overview of what happens when you fire your GEO3.5. The location of parts discussed in the text below can be found on pages 68-69.

Assuming the GEO3.5 is gassed up and turned on *figure 27A* shows the marker in its idle position. The firing chamber is full of compressed air, the prop shaft is pushed back into the back cap by this compressed air. The bolt is held back by the air in the bolt can. Both the firing chamber and the bolt can are supplied with air via the solenoid valve.

Providing a ball is in the breach when the trigger is pulled, a signal is sent to the solenoid valve which shuts off the supply of air to the firing chamber and allows the air in the bolt can to be exhausted. This removes the force holding the bolt in its rear position and the bolt is propelled forwards (*figure 27B*).


As the bolt passes the front prop shaft o-ring the firing chamber seal is broken and the air in the firing chamber vents down the bolt, in turn propelling a ball (*figure 27C*).

As air is vented from the firing chamber the force pushing the prop shaft back is overcome by the spring tension in the back cap. The spring, along with a small volume of air used to propel the paintball ported to the rear of the propshaft, pushes the prop shaft forward. The front 14x2 o-ring on the prop shaft seals off the firing chamber against the inside of the bolt (*figure 27D*).

The length of time the bolt remains in this forward position is dependant on dwell. When the solenoid has completed its dwell time, air is routed back into the bolt can and pushes the bolt back towards its rear position. Simultaneously the firing chamber is re-filled through the solenoid valve to the operating pressure set by the user via the inline regulator, and the prop shaft is pushed into its rear position by the air pressure inside the valve chamber (*figure 27E*).



PARTS LIST



PARTS LIST

- 01 Clamping feed tube assembly
- 02 Body
- 03 Bolt assembly
- 04 Rubber detent
- 05 BBSS unit
- 06 Front frame screw
- 07 Rear frame screw
- 08 Solenoid assembly
- 09 SL4 inline regulator assembly
- 10 Gas pipe
- 11 Pipe nut
- 12 Gas pipe assembly o-ring
- 13 Trigger assembly
- 14 Frame
- 15 9V battery
- 16 Printed circuit board
- 17 Push-button strip
- 18 Display window
- 19 PCB screw
- 20 Navigation console
- 21 POPS assembly
- 22 POPS seal
- 23 Foregrip crown
- 24 Foregrip sleeve
- 25 Rubber grip
- 26 Body plug
- 27 Body FRM o-ring
- 28 Body filter
- 29 Body filter retaining Screw
- 30 Solenoid flow restrictor
- 31 Solenoid flow restrictor seal

SHAFT BARREL SYSTEM


The Eclipse GEO3.5 comes as standard with an Eclipse Shaft4 barrel.^{1,4}

The barrel screws into the body of the GEO3.5 using a right hand thread meaning that if you hold the GEO3.5 pointing away from you the barrel screws into the body in a counter-clockwise direction.²

The barrel comprises of two parts, a barrel back **A** and a barrel front **B**. The two parts are joined together with a left hand thread meaning that if you hold the barrel, with the back nearest you, the front unscrews in a counter-clockwise direction. The bore size of the barrel back is engraved at the end of the barrel back **C**.³

On the barrel back there is a 016 NBR 70 o-ring **D** which prevents the barrel from vibrating loose from the GEO3.5 body when the marker is fired. There is also a 016 NBR 70 o-ring on the tip of the barrel back **E** helps with alignment when the two sections are screwed together.

Replace and lubricate these o-rings with Eclipse Grease as necessary.



¹ The bore size of your Shaft4 may vary according to the model of GEO3.5 you have.

² The GEO3.5 will only accept Cocker threaded barrels.
Do not use any other type of barrel thread.

³ The Eclipse Shaft4 front and back barrel sections are not interchangeable with older version Shaft front and back barrel sections (including Shaft3 barrel kits).

⁴ The model of barrel accompanying your GEO3.5 may differ from described.

SL4 INLINE REGULATOR^{1,2}

1 The SL4 inline regulator should be reset to factory after re-assembly.


2 Only use the SL4 inline regulator with the GEO3.5.

3 Only use the SL4 GEO spring with the GEO3.5 SL4 inline regulator.


4 If the Purge Poppet assembly is removed for maintenance ensure it is re-installed correctly, failure to do so may seriously damage the GEO3.5 solenoid valve.



GE03.5 BOLT SYSTEM




SOLENOID ASSEMBLY



The GEO3.5 solenoid valve is NON-SERVICEABLE. Any attempt to strip, dismantle or service the solenoid valve will immediately void your warranty. For more information on the GEO3.5 solenoid valve please see page 56.


GE03.5 PUSH ON PURGE SYSTEM (POPS)




TRIGGER ASSEMBLY




CLAMPING FEED TUBE ASSEMBLY



GE03.5 CIRCUIT BOARD



COMMON SCREW SIZE CHART

<i>SCREW TYPE</i>	<i>QTY</i>	<i>DESCRIPTION</i>
	6	PCB screw (3), bearing carrier screw (2), navigation console (1) (M2.5 X 5 cap head socket)
	2	Solenoid screw (2) (M2.5 X 12 cap head socket)
	6	Rubber grip screw (4), BBSS covers screw (2) (6-32 UNC x 5/16" countersunk socket)
	1	Short feed neck screw (10-32 UNF x 1/2" cap head socket)
	2	POPS screw (10-32 UNF x 1" cap head socket)
	1	Micro-switch screw (6-32 UNC x 1/2" socket set screw)
	2	Trigger adjustment screw (6-32 UNC x 3/16" socket set screw)
	3	Trigger pin retaining screw (6-32 UNC x 1/8" socket set screw)
	3	Frame screw (2), body filter (1) (10-32 UNF x 3/8 socket button head)

COMMON O-RING SIZE CHART

18x2		POPS Seal
14x2		SL4 Inline regulator piston Propshaft (x2) Bolt external
020		Bolt can external (x2) Prop shaft back cap
017		Front regulator mount (body) Bolt can internal
016		Shaft4 barrel back (body end) Shaft4 barrel back (tip end)

015		SL4 swivel Bolt bumper (middle) NBR90
013		ST bolt tip
011		SL4 inline regulator adjuster outside
		Propshaft retaining screw rear
008		SL4 inline regulator adjuster inside
007		Gas transfer pipe POPS insert external
006		Body plug Feed tube swivel
005		POPS insert internal (NBR 90)
004		POPS push rod
7x1		Propshaft tip
5x1		Solenoid flow restrictor (x2) Bolt plunger
		Propshaft retaining screw front
All o-rings are NBR70 durometer unless otherwise stated.		

THE MENU TREE

The  symbol indicates parameters that are locked when the Tournament Lock is on. See 'accessing the menu system' on page 27 for instruction on releasing the Tournament Lock.

Parameters followed by a * are part of the Smart Menu System and will only be displayed depending on your chosen settings. (e.g. The BS ON ROF parameter will only become available if the ROF CAP parameter is set to on).

MAIN MENU

TURN OFF		Turn off the GEO3.5
PRE-SET		
 LOAD	USER 1 USER 2 FACTORY (Default) NPPL PSP 10 PSP 12 MS 10 CANCEL	Load the USER 1 settings Load the USER 2 settings Load the default factory settings (semi-automatic) Load NPPL compliant settings Load the PSP 10 balls per second (BPS) compliant settings Load the PSP 12 balls per second (BPS) compliant settings Load Millennium Series 2010 compliant settings Cancel the load operation
 SAVE	USER 1 USER 2 CANCEL	Save the current settings as the USER 1 settings Save the current settings as the USER 2 settings Cancel the save operation
BACK		Return to Main Menu.
 FIRE MODE	SEMI (Default) RAMP CANCEL	Select semi-automatic mode of fire Select ramping mode of fire Cancel the mode selection
 ROF CAP	ON OFF (Default) CANCEL	Rate of fire cap on Rate of fire cap off Cancel selection
 BS ON ROF*	4.0 - 30.0 bps	Maximum rate of fire with breech sensor on (ROF CAP dependant). (Default 15.0bps)
 BS OFF ROF	4.0 - 15.0 bps	Maximum rate of fire with breech sensor off. (Default 10.0bps)

CONTINUED

RAMP SETUP* (fire mode dependant)

 TYPE	STEP (Default) LINEAR CANCEL	Step ramping Linear ramping Cancel selection
 RATE*	0 - 100%	Percentage linear ramp rate (TYPE dependant). (Default 50%)
 SEMI SHOTS	3 - 9	Number of shots before ramping can start. (Default 3)
 KICK IN	3.3 - 10.0 pps	Rate at which the trigger has to be pulled in pulls per second (pps) before ramping can start. (Default 5pps)
 SUSTAIN	3.3 - 10.0 pps	Rate at which the trigger has to be pulled in pulls per second (pps) in order to maintain ramping. (Default 5pps)
 RESTART	0.0 - 1.0 s	Time in seconds (s) after the last trigger pull during which ramp can be restarted. (Default 0.0s)
BACK		Return to Main Menu

TIMING

 DWELL	10.0 - 30.0 ms	Solenoid energise time in milliseconds (ms) for each shot. (Default 26.2ms)
 FSD COMP	0.0 - 5.0 ms	First shot drop-off compensation time in milliseconds (ms). (Default 5.0ms)
 FSD DELAY	00:00 - 04:00	First shot drop-off delay. (Default 00:30)
BACK		Return to Main Menu

FILTER

 DE-BOUNCE	LEVEL 9 LEVEL 8 - 2 LEVEL 1 CANCEL	Use trigger De-bounce level 9 (highest level of trigger bounce filtering) Use trigger De-bounce level 8 - 2. (Default LEVEL 5) Use trigger De-bounce level 1 (lowest level of trigger bounce filtering) Cancel De-bounce selection
 EMPTY	1.0 - 20.0 ms	Time in milliseconds (ms) that the breech must remain empty before the BBSS looks for a paintball. (Default 4.0ms)
 FULL	1.0 - 20.0 ms	Time in milliseconds (ms) that a paintball must be in the breech for the GEO3.5 to be ready to fire. (Default 4.0ms)
 PULL TM	3.0 - 25.0 ms	Time in milliseconds (ms) that the trigger must be pulled for a shot to be fired. (Default 6.0m)
 RELEASE TM	3.0 - 25.0 ms	Time in milliseconds (ms) that the trigger must be released before a pull can be recorded. (Default 6.0ms)
 PULL PT*	51 - 99%	Percentage at which the trigger OPTO sensor pull point is set (TRIGGER dependant). (Default 85%)
 RELEASE PT*	1 - 49%	Percentage at which the trigger OPTO sensor release point is set (TRIGGER dependant). (Default 15%)
BACK		Return to Main Menu

CONTINUED

HARDWARE



TRIGGER

OPTO (Default) Use OPTO sensor to detect trigger operation
 SWITCH Use micro-switch to detect trigger operation
 CANCEL Cancel trigger detection method selection



SOLENOID

LO PWR (Default) Select standard solenoid power level
 HI PWR Select high power level for solenoid
 CANCEL Cancel solenoid power level selection

SOUND

OFF Turn off audible indicator
 ON (Default) Turn on audible indicator
 CANCEL Cancel audible indicator selection

TONES

OFF Turn off audible tone when any button is pressed (SOUND dependant)
 ON (Default) Turn on audible tone when any button is pressed (SOUND dependant)
 CANCEL Cancel audible tone selection

BACKLIGHT

00:00 - 00:20 Time in seconds that the backlight comes on for (00:00 = no backlight). (Default 00:06)

RED LEVEL

0 - 100% Percentage of red light in backlight (BACKLIGHT dependant)

GRN LEVEL

0 - 100% Percentage of green light in backlight (BACKLIGHT dependant)

BLU LEVEL

0 - 100% Percentage of blue light in backlight (BACKLIGHT dependant)

CONTRAST

0 - 30 LCD contrast level. (Default 14)

AUX OUT

OFF AUX socket output off
 ON (Default) AUX socket output on
 CANCEL Cancel AUX socket selection

AUTO OFF

05:00 - 60:00 Time in minutes after which the GEO3.5 automatically powers off. (Default 20:00)

DBL CLICK

NONE Double click is disabled entirely
 POWER UP Double click for power up only
 ALL (Default) Double click is fully enabled
 CANCEL Cancel the double click selection

BACK

Return to Main Menu

TRAINING

OFF Training mode disabled
 ON Training mode enabled
 CANCEL Cancel training mode selection

CONTINUED

SHOT COUNT							
GAUGE	<table border="1"> <tr> <td>OFF</td> <td>Shot gauge off</td> </tr> <tr> <td>ON (Default)</td> <td>Shot gauge on</td> </tr> <tr> <td>CANCEL</td> <td>Cancel selection</td> </tr> </table>	OFF	Shot gauge off	ON (Default)	Shot gauge on	CANCEL	Cancel selection
OFF	Shot gauge off						
ON (Default)	Shot gauge on						
CANCEL	Cancel selection						
GAUGE MAX	<table border="1"> <tr> <td>100-2000</td> <td>Shot gauge maximum (reset value) (GAUGE dependant). (Default 140 shots)</td> </tr> </table>	100-2000	Shot gauge maximum (reset value) (GAUGE dependant). (Default 140 shots)				
100-2000	Shot gauge maximum (reset value) (GAUGE dependant). (Default 140 shots)						
BACK	Return to Main Menu						
GAME TIMER							
GAUGE	<table border="1"> <tr> <td>00:00 - 60:00</td> <td>Countdown game timer start time in minutes. (Default 07:10)</td> </tr> </table>	00:00 - 60:00	Countdown game timer start time in minutes. (Default 07:10)				
00:00 - 60:00	Countdown game timer start time in minutes. (Default 07:10)						
ALARM	<table border="1"> <tr> <td>00:00 - 60:00</td> <td>Alarm activation time in minutes. (Default 01:00)</td> </tr> </table>	00:00 - 60:00	Alarm activation time in minutes. (Default 01:00)				
00:00 - 60:00	Alarm activation time in minutes. (Default 01:00)						
START	<table border="1"> <tr> <td>BUTTON (Default)</td> <td>Pressing the ♥ button starts the Game Timer.</td> </tr> <tr> <td>TRIGGER</td> <td>A trigger pull starts the Game Timer</td> </tr> <tr> <td>CANCEL</td> <td>Cancel Game Timer start selection</td> </tr> </table>	BUTTON (Default)	Pressing the ♥ button starts the Game Timer.	TRIGGER	A trigger pull starts the Game Timer	CANCEL	Cancel Game Timer start selection
BUTTON (Default)	Pressing the ♥ button starts the Game Timer.						
TRIGGER	A trigger pull starts the Game Timer						
CANCEL	Cancel Game Timer start selection						
BACK	Return to Main Menu						
EXIT							

From time to time the software of the GEO3.5 may be updated, resulting in changes to the default values for some parameters. For the most up to date default values please consult the online version of this manual at www.planeteclipse.com

The arrangement of menus and sub menus displayed in the above menu tree may not be replicated in your marker due to any software updates that may have taken place since printing.

ECLIPSE E-PORTAL

The GEO3.5 is compatible with Eclipse E-Portal Software. This software is an upgrade to the GEO3.5 platform. The Eclipse E-Portal Software, USB cable and USB daughter board are sold as a kit, separate from the GEO3.5.¹

E-Portal allows you to connect the Eclipse GEO3.5 to a PC, where a number of operations can be performed:²

- Update the marker firmware - from time to time new firmware may be released by Planet Eclipse. You can now install the latest firmware using the Eclipse E-Portal.
- Alter the electronic parameters - the Eclipse E-Portal will give you full access to all of the parameters on the GEO3.5 circuit board
- Customise screen graphics - customise the boot up screen graphic.

WARNING!




Always de-gas your marker, discharging any stored gas in a safe direction, and remove the barrel, loader, air system and any paintballs to make the marker easier and safer to work on.

¹ If you already own an Eclipse E-portal kit (such as the kit included with the Eclipse SLS or CSL Ego and GSL GEO), this kit will be compatible with the GEO3.5.


² Minimum system requirements:

Monitor Resolution - 1024x768 or higher, CD-ROM drive, Keyboard, Mouse, USB socket, 5MB of hard disk space, 1GHz Processor, 384Mb RAM, Microsoft® Windows® XP / Windows Vista / Windows 7 / Windows 8, internet connection (required for software and firmware updates).


PC



USB



GEO 3.5



And any other Eclipse E-Portal compatible markers.

INDEX

Actual rate of fire.....22, 26
Advanced trigger filter setup.....36
Air system.....6, 16, 17, 18, 20
ALARM.....25, 41, 82
AUTO OFF.....39, 81
AUX OUT.....22, 23, 39, 81
BACKLIGHT.....10, 38, 81
Basic trigger filter set-up.....36, 64
Battery.....7, 21, 22, 37, 61, 64, 69, 76
Battery level indicator.....22, 25
BBSS socket.....76
Bearing carrier assembly.....51, 54, 55, 75
Bearing carrier screw.....75, 77
BLU LEVEL.....38, 83
Blanking plug.....19, 53
Body filter.....47, 62, 63, 69, 77
Body plug.....45, 69, 78
Bolt.....48-49, 62-64, 67, 69, 72
Bolt bumper o-ring.....72, 78
Bolt front o-ring.....72, 78
Bolt rear o-ring.....72, 78
Bolt system.....48-50, 69, 72
Bolt tip.....49, 64, 72
Bolt can.....48-49, 63, 67, 72
Bolt can external o-rings.....72, 78
Bolt can internal o-ring.....72, 78
Break beam sensor system (BBSS).....9, 10, 23, 42-43, 61-65, 69, 76
Break beam sensor system indicator.....23
BS OFF ROF.....23, 30, 79
BS ON ROF.....23, 30, 79
CANCEL.....27
Clamping feed sprocket screw.....14, 20, 75
Clamping feed swivel.....75
Clamping feed tube.....20, 75
Clamping feed tube screw.....75, 77
Clamping lever.....14, 75
Clamping feed tube insert.....75
Circuit board (PCB).....69, 76

Contrast.....39, 81
DBL CLICK.....39, 81
DE-BOUNCE.....34, 36, 66, 80
DWELL.....33, 62, 80
E-Portal.....83
EMPTY.....34, 80
EXIT.....82
Eye cover.....42, 43
Eye cover screw.....42, 43, 77
FACTORY.....6, 29, 79
FILTER.....34, 80
FIRE MODE.....30, 79
Foregrip crown.....44-45, 51-52, 69
Foregrip sleeve.....18, 44, 69
Frame.....51-52, 69
Frame screw.....51-52, 69, 77
Front stop trigger screw.....12-13, 36, 75, 77
FSD COMP.....33, 64, 80
FSD DELAY.....33, 80
FULL.....34, 80
GAME.....41, 82
Game timer.....22, 25, 41, 82
Gas pipe.....15, 69, 78
GAUGE.....25, 40, 82
GAUGE MAX.....40, 82
GRN LEVEL.....38, 81
HARDWARE.....36, 81
Inline regulator adjuster screw.....18, 71, 78
Inline regulator assembly.....69, 71
Inline regulator body.....71
Inline regulator bottom.....71
Inline regulator piston.....71, 78
Inline regulator spring.....71
Inline regulator swivel.....15, 71, 78
KICK IN.....32, 80
Latch button.....74
LINEAR.....31, 80
LOAD.....29, 79

Lock indicator.....22, 25, 27, 79
Magnet return strength screw.....13, 77, 79
Main menu.....27, 28, 79
Menu system.....26, 28, 79-82
Menu tree.....79-82
Micro-switch activation screw.....13, 76, 77
MS 10.....29, 79
Navigation console.....10, 22, 69
NPPL.....29, 79
Parameters.....10, 26, 27, 28
PCB retaining screw.....77
Peak rate of fire.....22, 26
Pipe nut.....15, 71, 78
Plastic push-button strip.....69
Poppet.....14
Poppet cap.....14
POPS body.....74
POPS bonnet.....74
POPS insert.....74
POPS pin.....74
Pop retaining screws.....74, 77
PRESET.....29, 79
Prop shaft.....48-50, 67, 72
Prop shaft back cap.....48-50, 72
Prop shaft back cap o-ring.....48-50, 72, 78
Prop shaft bumper.....48-50, 72
Prop shaft middle o-ring.....48-50, 72, 78
Prop shaft spring.....48-50, 72
Prop shaft tip.....48-50, 72
PSP 10.....29, 79
PSP 12.....29, 79
PULL PT.....35, 80
PULL TM.....35, 80
Purge poppet assembly.....73
Push Operated Purge System (POPS).....69,74
RAMP.....30, 79
RAMP SET UP.....31, 80
RATE.....31, 80
Rear stop trigger screw.....12, 75, 77
RED LEVEL.....38, 81
Regulator seal.....71
RELEASE PT.....35, 80
RELEASE TM.....35, 80
RESTART.....32, 80

ROF CAP.....30, 79
Rubber detent.....43, 69
Rubber grip screw.....77
Run screen layout.....22
SL4 inline regulator.....69
SAVE.....29, 79
SEMI.....30, 79
SEMI SHOTS.....32, 80
Shaft4 barrel.....11, 70
SHOT COUNT.....22, 25, 40, 82
SOLENOID.....37, 81
Solenoid assembly.....56-58, 61, 63, 73
Solenoid Flow Restrictor (SFR).....6, 19, 53, 61-64, 69, 78
Solenoid manifold.....56-58, 62-63, 73
Solenoid manifold bottom gasket.....56-58, 73
Solenoid manifold top gasket.....56-58, 73
Solenoid retaining screw.....56-58, 73, 77
Solenoid valve.....56-58, 61, 63, 73
Solenoid valve gasket.....56-58, 73
SOUND.....37, 81
Sound indicator.....22, 24
Spring return strength screw.....13, 75, 77
START.....41, 82
STEP.....31, 80
SUSTAIN.....32, 80
TIMING.....33, 80
TONES.....37, 81
TRAINING.....23, 40, 81
Trigger.....8, 12, 13, 54, 55, 75
TRIGGER.....81
Trigger assembly.....69, 75
Trigger Detection Indicator (TDI).....13, 24
Trigger pin.....12, 75
Trigger pin locking set screw.....12, 75
Trigger leaf spring.....12, 75
TURN OFF.....8, 10, 28, 79
TYPE.....31, 80
USB CABLE.....83
USER1.....29, 79
USER2.....29, 79
User interface.....22
Velocity.....18



**GET MORE
PLANETECLIPSE.COM**



This product is covered by and / or licensed under one or more of the following patents:

G.B. Patents: 2,342,710; 2,345,953; 2,352,022; 2,391,292; 2,391,063.

U.S. Patents: 7,836,873; 7,603,995; 7,073,284; 8,104,463; 7,509,953; 7,921,839; 7,089,697; 7,866,307; 8,082,912; 7,076,906; 7,607,424; 7,980,238; 6,311,682; 6,748,938; 6,860,259; 6,941,693; 6,973,748; 5,881,707; 5,967,133; 6,035,843; 6,474,326; 6,637,421; 6,644,295; 6,810,871; 6,901,923; 7,121,272; 7,100,593; 7,610,908; 7,603,997; 7,946,285; 6,349,711; 7,044,119; 7,185,646; 7,461,646; 7,556,032; 7,591,262; 7,617,819; 7,617,820; 7,624,723; 7,640,925; 7,640,926; 7,866,308.

Application Numbers:

12/256,832; 12/613,958; 12/493,777; 11/654,721; 11/747,107; 12/503,504; 11/781,821; 60/832,548; 11/965,886; 10/280,115; 12/511619; 13/182135; 13/334575; 13/165234.

Additional U.S. and International Patents may be pending.

© 2014 Copyright Planet Eclipse Ltd. Eclipse, Planet Eclipse, the Estar Logo Device, Ego, Geo, Etek, Etha and EMC are all either design trademarks, registered trademarks or trademarks of Planet Eclipse Ltd. All other trademarks are property of their respective owners.



802.055.A-000

USA
130 Franklin Street
Building L4 & L5
Warren, RI, 02885, USA
Call: +1 401 247 9061
info.usa@planetecclipse.com

UK
Unit 14 Premier Park, Acheson Way
Trafford Park Road, Trafford Park
Manchester, M17 1GA, England
Call: +44(0) 161 872 5572
info.europe@planetecclipse.com